

XBA mini-MVR6

XBA mini Option Switch Settings: 1(Pulse/MDB/JPSTD/ICT104V/ICT104U)

Supported bill MVR 10, 20, 50, 100, 500, 1000 6bills.

XBA mini dip-switch settings and functions:

	FUNCTION	SW1	SW2	SW3	SW4	SW5	SW6	SW7	SW8	SW1	SW2	SW3	SW4
★	Reject MVR 10	ON											
★	Accept MVR 10	OFF											
★	Reject MVR 20 & 50		ON										
★	Accept MVR 20 & 50		OFF										
★	Reject MVR 100			ON									
★	Accept MVR 100			OFF									
★	Reject MVR 500				ON								
★	Accept MVR 500				OFF								
★	Reject MVR 1000				ON								
★	Accept MVR 1000				OFF								
★	Disable Bill Reject 4 Times BA Stop By 30 Sec					ON							
★	Enable Bill Reject 4 Times BA Stop By 30 Sec					OFF							
★	Stack Banknote when Power-up						ON						
★	Reject Banknote when Power-up						OFF						
★	Reserved							ON					
★	Reserved							OFF					
★	Inhibit Active High							ON					
★	Inhibit Active Low							OFF					
★	Reserved							ON					
★	Reserved							OFF					
★	Interface Timing Conversion	50ms LO / 50ms HI								OFF	OFF		
		60ms LO / 300ms HI								ON	OFF		
		30ms LO / 50ms HI								OFF	ON		
		150ms LO / 150ms HI								ON	ON		

★ Manufacture setting

Note : (1) After setting dip switch of the credit pulses, you should reset the bill acceptor again.
(2) Calibration card is needed.

XBA mini-MVR6(Pulse/MDB/JPSTD/ICT104V/ICT104U)

Interface Settings: 2(Pulse)

	INTERFACE	SW1	SW2	SW3	SW4
★	Credit-Pulse Normal HIGH	ON			
	Credit-Pulse Normal LOW	OFF			
★	Pulse Mode		ON		
	Other Mode		OFF		
★	1 pulse / MVR 10			OFF	OFF
	5 pulses / MVR 10			OFF	ON
	10 pulses / MVR 10			ON	OFF
	20 pulses / MVR 10			ON	ON

★ Manufacture setting

Currency Assign Data

Interface Bill value	JPSTD	ICT104U	ICT104V	Pulse	MDB
BV1	MVR 10	MVR 10	MVR 10	MVR 10	MVR 10
BV2		MVR 20	MVR 20	MVR 20	MVR 20
BV3		MVR 50	MVR 50	MVR 50	MVR 50
BV4		MVR 100	MVR 100	MVR 100	MVR 100
BV5		MVR 500	MVR 500	MVR 500	MVR 500
BV6		MVR 1000	MVR 1000	MVR 1000	MVR 1000

Interface Settings: 2(Other)

	INTERFACE	SW1	SW2	SW3	SW4
★	Reserved	ON			
	Reserved	OFF			
	Pulse Mode		ON		
★	Other Mode		OFF		
	MDB Mode			OFF	OFF
	JPSTD Mode			OFF	ON
	ICT104U Mode			ON	OFF
	ICT104V Mode			ON	ON

★ Manufacture setting

Interface Settings: 2(ICT104V)

	INTERFACE	SW1	SW2	SW3	SW4
★	Connect with coin changer	ON			
	Connect with ICT JPSTD Converter board	OFF			
	Pulse Mode		ON		
★	Other Mode		OFF		
	MDB Mode			OFF	OFF
	JPSTD Mode			OFF	ON
	ICT104U Mode			ON	OFF
★	ICT104V Mode			ON	ON

★ Manufacture setting

Interface Settings: 2(MDB)

	FUNCTION	SW1	SW2	SW3	SW4
★	Scaling Factor (SF) = 1000 Decimal Point Position (DPP) = 2	ON			
	Scaling Factor (SF) = 10 Decimal Point Position (DPP) = 0	OFF			
	Pulse Mode		ON		
★	Other Mode		OFF		
★	MDB Mode			OFF	OFF
	JPSTD Mode			OFF	ON
	ICT104U Mode			ON	OFF
	ICT104V Mode			ON	ON

★ Manufacture setting