


## XBA-UAH9 Option Switch Settings

Supported bill H 1, 2, 5, 10, 20, 50, 100, 200, 500 9bills.

|   | FUNCTION   | SW1 | SW2 | SW3 | SW4 | SW5 | SW6 | SW7 | SW8 |
|---|--|-----|-----|-----|-----|-----|-----|-----|-----|
| ★ | Reject H 1 & 2                                   | ON  |     |     |     |     |     |     |     |
| ★ | Accept H 1 & 2                                   | OFF |     |     |     |     |     |     |     |
| ★ | Reject H 5 & 10                                  |     |     |     |     |     |     |     |     |
| ★ | Accept H 5 & 10                                  |     | ON  |     |     |     |     |     |     |
| ★ | Reject H 20 & 50                                 |     | OFF |     |     |     |     |     |     |
| ★ | Accept H 20 & 50                                 |     |     |     |     |     |     |     |     |
| ★ | Reject H 100 & 200                               |     |     | ON  |     |     |     |     |     |
| ★ | Accept H 100 & 200                               |     |     | OFF |     |     |     |     |     |
| ★ | Reject H 500                                     |     |     |     |     |     |     |     |     |
| ★ | Accept H 500                                     |     |     |     | ON  |     |     |     |     |
| ★ | Disable Bill Reject 4 Times<br>BA Stop By 30 Sec |     |     |     | OFF |     |     |     |     |
| ★ | Enable Bill Reject 4 Times<br>BA Stop By 30 Sec  |     |     |     |     |     |     |     |     |
| ★ | Stack Banknote when Power-up                     |     |     |     |     | ON  |     |     |     |
| ★ | Reject Banknote when Power-up                    |     |     |     |     | OFF |     |     |     |
| ★ | Reserved   |     |     |     |     |     |     |     |     |
| ★ | Reserved   |     |     |     |     |     |     | ON  |     |

This dip switch is located at the side of XBA.



### Currency Assign Data

| Interface | Bill value | Pulse            |                   | MDB              |                   | ccNet | RS232 A0 | ICT104U |
|-----------|------------|------------------|-------------------|------------------|-------------------|-------|----------|---------|
|           |            | When Dip 1 is ON | When Dip 1 is OFF | When Dip 1 is ON | When Dip 1 is OFF |       |          |         |
| BV1       |            | H 1              | H 5               | H 1              | H 1               | H 1   | H 1      | H 1     |
| BV2       |            | H 2              | H 10              | H 2              | H 2               | H 2   | H 2      | H 2     |
| BV3       | H 5        | H 5              | H 20              | H 5              | H 5               | H 5   | H 5      | H 5     |
| BV4       | H 10       | H 10             | H 50              | H 10             | H 10              | H 10  | H 10     | H 10    |
| BV5       | H 20       | H 20             | H 100             | H 20             | H 20              | H 20  | H 20     | H 20    |
| BV6       | H 50       | H 50             | H 200             | H 50             | H 50              | H 50  | H 50     | H 50    |
| BV7       | H 100      | H 100            | H 500             | H 100            | H 100             | H 100 | H 100    | H 100   |
| BV8       | H 200      | H 200            |                   | H 200            | H 200             | H 200 | H 200    | H 200   |
| BV9       | H 500      | H 500            |                   | H 500            | H 500             | H 500 | H 500    | H 500   |

#### RS232 A0 INFORMATION

| BillType Data |              |
|---------------|--------------|
| Code          | Denomination |
| 1             | H 1          |
| 2             | H 2          |
| 3             | H 5          |
| 4             | H 10         |
| 5             | H 20         |
| 6             | H 50         |
| 7             | H 100        |
| 8             | H 200        |
| 9             | H 500        |


### Appendix

## XBA-UAH9 (Pulse/MDB/RS232 A0/ccNet/ICT104U)

| FUNCTION |  | SW1   | SW2 | SW3             | SW4 | SW5 | SW6 | SW7 | SW8 |
|----------|--|---|-----|-----------------|-----|-----|-----|-----|-----|
| ★        | Inhibit Active HIGH                                    | ON  |     |                 |     |     |     |     |     |
|          | Inhibit Active LOW                                     | OFF   |     |                 |     |     |     |     |     |
| ★        | Reserved   |   | ON  |                 |     |     |     |     |     |
|          | Reserved   |   | OFF |                 |     |     |     |     |     |
| ★        | Reserved   |   |     | ON              |     |     |     |     |     |
|          | Reserved   |   |     | OFF             |     |     |     |     |     |
| ★        | Reserved   |   |     |                 | ON  |     |     |     |     |
|          | Reserved   |   |     |                 | OFF |     |     |     |     |
| ★        | Pulse Mode   | MDB Mode  |     | ccNet Mode      |     |     |     |     |     |
|          | Credit-Pulse Normal HIGH                               | Scaling Factor (SF) = 100<br>Decimal Point Position (DPP) = 2 |     | 9600 Baud Rate  |     |     |     |     |     |
| ★        | Credit-Pulse Normal LOW                                | Scaling Factor (SF) = 1<br>Decimal Point Position (DPP) = 0   |     | 19200 Baud Rate |     |     | OFF |     |     |
|          | Pulse Mode   |   |     |                 |     |     | ON  |     |     |
| ★        | Other Mode   |   |     |                 |     |     | OFF |     |     |
|          | 1 pulse / <div>H 1 (Dip1:OFF)<br/>H5 (Dip1:ON)</div>   | MDB Mode  |     |                 |     |     | OFF |     |     |
| ★        | 5 pulses / <div>H 1 (Dip1:OFF)<br/>H5 (Dip1:ON)</div>  | RS232 A0 Mode   |     |                 |     |     | OFF | ON  |     |
|          | 10 pulses / <div>H 1 (Dip1:OFF)<br/>H5 (Dip1:ON)</div> | ccNet Mode  |     |                 |     |     | ON  | OFF |     |
| ★        | 25 pulses / <div>H 1 (Dip1:OFF)<br/>H5 (Dip1:ON)</div> | ICT104U   |     |                 |     |     | ON  | ON  |     |

★ Manufacture setting

This dip switch is located on the CPU board, remove the CPU board cover first.



\*\*After setting dip switch of the credit pulses, you should reset the bill acceptor again.

Note : 1.No sleep function.  
2.Calibration card is needed.