


XBA-RON5 Option Switch Settings

Supported bill RON 1, 5, 10, 20, 50 5bills.

	FUNCTION	SW1	SW2	SW3	SW4	SW5	SW6	SW7	SW8
	Reject RON 1	ON							
★	Accept RON 1	OFF							
	Reject RON 5		ON						
★	Accept RON 5		OFF						
	Reject RON 10			ON					
★	Accept RON 10			OFF					
	Reject RON 20				ON				
★	Accept RON 20				OFF				
	Reject RON 50					ON			
★	Accept RON 50					OFF			
	Disable Bill Reject 4 Times BA Stop By 30 Sec						ON		
★	Enable Bill Reject 4 Times BA Stop By 30 Sec						OFF		
	Stack Banknote when Power-up							ON	
★	Reject Banknote when Power-up							OFF	
	Test Mode (Pulse only)								ON
★	Operation Mode								OFF

This dip switch is located at the side of XBA.




Currency Assign Data

Interface Bill value	ICT104U	ICT104V	Pulse	MDB
BV1	RON 1	RON 1	RON 1	RON 1
BV2	RON 5	RON 5	RON 5	RON 5
BV3	RON 10	RON 10	RON 10	RON 10
BV4	RON 50	RON 50	RON 50	RON 50
BV5	RON 20	RON 20	RON 20	RON 20

XBA-RON5 (Pulse/MDB/ICT104U/ICT104V)

	FUNCTION	SW1	SW2	SW3	SW4	SW5	SW6	SW7	SW8
	Inhibit Active HIGH	ON							
★	Inhibit Active LOW	OFF							
	Reserved		ON						
★	Reserved		OFF						
★	50ms LO / 50ms HI			OFF	OFF				
	50ms LO / 100ms HI			OFF	ON				
	65ms LO / 75ms HI			ON	OFF				
	100ms LO / 150ms HI			ON	ON				
	Pulse Mode	MDB Mode			ICT104V Mode				
★	Credit-Pulse Normal HIGH	Scaling Factor (SF) = 100 Decimal Point Position (DPP) = 2			Connect with coin changer		ON		
	Credit-Pulse Normal LOW	Scaling Factor (SF) = 1 Decimal Point Position (DPP) = 0			Connect with ICT JPSTD converter board		OFF		
★	Pulse Mode							ON	
	Other Mode							OFF	
	Pulse Mode	Other Mode							
★	1 pulse / RON 1	MDB Mode							
	2 pulses / RON 1	Reserved							
	10 pulses / RON 1	ICT104U Mode							
	20 pulses / RON 1	ICT104V Mode							

This dip switch is located on the CPU board, remove the CPU board cover first.



★ Manufacture setting

Note : 1.After setting dip switch of the credit pulses, you should reset the bill acceptor again.
2.Calibration card is needed.