

BR2300-VND9

BR2300 DIP SWITCHES SETTING : (MDB/ICT104R/ccTalk)

Supported bill VND 1000, 2000, 5000, 10000, 20000

50000, 100000, 200000, 500000 9 bills.

	FUNCTION	SW1	SW2	SW3	SW4	SW5	SW6	SW7	SW8	SW9	SW10
	Reject VND 1000 & 2000 (Note.3)	ON									
★	Accept VND 1000 & 2000 (Note.3)	OFF									
	Reject VND 5000 & 10000 & 20000 & 50000		ON								
★	Accept VND 5000 & 10000 & 20000 & 50000		OFF								
	Reject VND 100000 & 200000 & 500000			ON							
★	Accept VND 100000 & 200000 & 500000			OFF							
	High Acceptance (Note.5)				ON						
★	High Security				OFF						
	Credit divide by 100 (MDB only) (Note.7)					ON					
★	Normal (Note.6)					OFF					
★	Normal						OFF	OFF			
	Load Banknote to Recycle						ON	OFF			
	Load Banknote to Stacker						OFF	ON			
	Unload Banknote to Stacker						ON	ON			
★	ccTalk								ON	OFF	
	ccTalk (Note.1)								OFF	ON	
★	MDB Mode								OFF	OFF	
★	ICT104R Mode								ON	ON	
	ccTalk	MDB Mode				ICT104R Mode					
★	Encryption MODE	Virtual MDB Recycler Function (Note.2)				Reserved					ON
	Decrypt MODE	Standard MDB Recycler Function				Reserved					OFF

★ Manufacture setting

After setting dip switch of the credit pulses, you should reset the bill acceptor again.

Note.1: Turn this dip to with restart the bill acceptor will restore ccTalk address to its default value of 40 and the encryption key to its default value of 123456.

Note.2: Recycled Banknote represents virtual MDB coin type.

Note.3:** MDB Mode:

When Dip 1 is OFF, Reject VND 500000.

When Dip 1 is ON, Accept VND 500000.

Note.4: calibrate card.

Note.5: High acceptance mode will increase accepting rate, however, it will reduce the security level of Bill Acceptor.

Note.6: Normal: Scaling Factor (SF) = 1

Decimal Point Position (DPP) = 0

Note.7: The function (credit divide by 100) is only used at standard MDB recycler mode

BR2300-VND9 (MDB/ICT104R/ccTalk)

Currency Assign Data

Interface Bill value	ccTalk	ICT104R	MDB					
			When Dip 1 is OFF			When Dip 1 is ON		
				Note.1	Note.2		Note.1	Note.2
BV1	VND 1000	VND 1000	VND 1000	VND 1000	VND 10	VND 5000	VND 5000	VND 50
BV2	VND 2000	VND 2000	VND 2000	VND 2000	VND 20	VND 10000	VND 10000	VND 100
BV3	VND 5000	VND 5000	VND 5000	VND 5000	VND 50	VND 20000	VND 20000	VND 200
BV4	VND 10000	VND 10000	VND 10000	VND 10000	VND 100	VND 50000	VND 50000	VND 500
BV1	VND 20000	VND 20000	VND 20000	VND 20000	VND 200	VND 100000	VND 100000	VND 1000
BV2	VND 50000	VND 50000	VND 50000	VND 50000	VND 500	VND 200000	VND 200000	VND 2000
BV3	VND 100000	VND 100000	VND 100000	VND 100000	VND 1000	VND 500000	VND 500000	VND 5000
BV4	VND 200000	VND 200000	VND 200000	VND 200000	VND 2000			
BV4	VND 500000	VND 500000						

Note.1: Normal: Scaling Factor (SF) = 1

Decimal Point Position (DPP) = 0

Note.2: The function (credit divide by 100) is only used at standard MDB recycler mode