

## L83-EUR4

### L83-P3/P6 DIP SWITCHES SETTING : 1(Pulse/ccTalk/Smiley Parallel)

Supported bill € 5, 10, 20, 50 4bills.

FUNCTION	SW1	SW2	SW3	SW4	SW5	SW6	SW7	SW8	SW9	SW10
★ 1 Pulse / € 5	OFF	OFF	OFF							
2 Pulse / € 5	OFF	OFF	ON							
3 Pulse / € 5	OFF	ON	OFF							
4 Pulse / € 5	OFF	ON	ON							
5 Pulse / € 5	ON	OFF	OFF							
10 Pulse / € 5	ON	OFF	ON							
20 Pulse / € 5	ON	ON	OFF							
100 Pulse / € 5	ON	ON	ON							
Fast output Pulse <small>Lo= 50ms Hi=100ms</small>				ON						
★ Slow output Pulse <small>Lo= 50ms Hi=300ms</small>				OFF						
Inhibit level Active Low					ON					
Inhibit level Active High					OFF					
★ Accept € 5						ON				
Reject € 5						OFF				
★ Accept € 10							ON			
Reject € 10							OFF			
★ Accept € 20								ON		
Reject € 20								OFF		
★ Accept € 50									ON	
Reject € 50									OFF	
★ Accept Normal										ON
Reject € 5(2002) & 10(2002)										OFF

★ Manufacture setting

Note.1 Please reset the bill acceptor after any changes on Dip switch.

2 Dip Switch 1 to 5 are only for Pulse mode.

3 Turn this dip to with restart the bill acceptor will restore ccTalk address to its default value of 40 and the encryption key to its default value of 123456.

## L83-EUR4(Pulse/ccTalk/Smiley Parallel)

### DIP SWITCHES SETTING : 2(Pulse)

FUNCTION	SW1	SW2	SW3	SW4
★ Pulse Normal High	ON			
Pulse Normal Low	OFF			
★ Pulse Mode		ON	OFF	
ccTalk Interface		OFF	OFF	
Smiley Parallel Mode		ON	ON	
ccTalk Parameters Restore Switch (Please see Note.3 for Detail)		OFF	ON	
★ Reserved				ON OFF

★ Manufacture setting

### DIP SWITCHES SETTING : 2(ccTalk)

FUNCTION	SW1	SW2	SW3	SW4
★ CRC 16-bit checksum	ON			
8-bit checksum	OFF			
Pulse Mode		ON	OFF	
★ cctalk Interface		OFF	OFF	
Smiley Parallel Mode		ON	ON	
ccTalk Parameters Restore Switch (Please see Note.3 for Detail)		OFF	ON	
★ Encryption Mode				ON
Decrypt Mode				OFF

★ Manufacture setting

Note: Put this switch to on and reset power will restore the ccTalk address to its default value of 40 and the encryption key to its default value of 123456.

### DIP SWITCHES SETTING : 2(Smiley Parallel)

FUNCTION	SW1	SW2	SW3	SW4
★ Reserved	ON OFF			
Pulse Mode		ON	OFF	
cctalk Interface		OFF	OFF	
★ Smiley Parallel Mode		ON	ON	
ccTalk Parameters Restore Switch (Please see Note.3 for Detail)		OFF	ON	
★ Reserved				ON OFF

★ Manufacture setting

### Currency Assign Data

Interface Bill value	Pulse	ccTalk	Smiley Parallel
BV1	€ 5	€ 5	€ 5
BV2	€ 10	€ 10	€ 10
BV3	€ 20	€ 20	€ 20
BV4	€ 50	€ 50	€ 50