

L83-EUR6

L83-P3/P6 DIP SWITCHES SETTING : 1(ccTalk/RS232 A0/RS232 A1)

Supported bill Euro 5, 10, 20, 50, 100, 200 6bills.

FUNCTION	SW1	SW2	SW3	SW4	SW5	SW6	SW7	SW8	SW9	SW10
★ Reserve	ON									
	OFF									
★ Reserve		ON								
		OFF								
★ Reserve			ON							
			OFF							
★ Reserve				ON						
				OFF						
★ Reserve					ON					
					OFF					
★ Accept Euro 5 & 10						ON				
★ Reject Euro 5 & 10						OFF				
★ Accept Euro 20 & 50							ON			
★ Reject Euro 20 & 50							OFF			
★ Accept Euro 100								ON		
★ Reject Euro 100								OFF		
★ Accept Euro 200									ON	
★ Reject Euro 200									OFF	
★ Accept Normal										ON
★ Reject Euro 5(2002) & 10(2002)										OFF

★ Manufacture setting

Note:(1) Please reset the bill acceptor after set the dip switch.

(2) Dip switches 1 to 5 are only used for pulse protocol.

(3) Turn this dip to with restart the bill acceptor will restore ccTalk address to its default value of 40 and the encryption key to its default value of 123456.

L83-EUR6(ccTalk/RS232 A0/RS232 A1)

DIP SWITCHES SETTING : 2(ccTalk)

FUNCTION	SW1	SW2	SW3	SW4
★ ccTalk	OFF	OFF		
RS232 A0	ON	OFF		
RS232 A1	OFF	ON		
Reserved	ON	ON		
★ ccTalk Parameters Restore Switch Please see "Note" for detail			ON	
★ ccTalk Interface			OFF	
★ Encryption Mode				ON
★ Decrypt Mode				OFF

★ Manufacture setting

Note: Turn this dip to with restart the bill acceptor will restore ccTalk address to its default value of 40 and the encryption key to its default value of 123456.

DIP SWITCHES SETTING : 2(RS232 A1)

FUNCTION	SW1	SW2	SW3	SW4
★ ccTalk	OFF	OFF		
RS232 A0	ON	OFF		
★ RS232 A1	OFF	ON		
Reserved	ON	ON		
★ Reserved			ON	
			OFF	
★ Reserved				ON
				OFF

★ Manufacture setting

DIP SWITCHES SETTING : 2(RS232 A0)

FUNCTION	SW1	SW2	SW3	SW4
★ ccTalk	OFF	OFF		
★ RS232 A0	ON	OFF		
RS232 A1	OFF	ON		
Reserved	ON	ON		
★ Reserved			ON	
			OFF	
★ Reserved				ON
				OFF

★ Manufacture setting

RS232 A0 INFORMATION

BillType Data	
Code	Denomination
1	Reserved
2	Euro 5
3	Euro 10
4	Euro 20
5	Euro 50
6	Euro 100
7	Euro 200
8	Reserved

Currency Assign Data

Interface Bill value	RS232 A0	RS232 A1	ccTalk
BV1	Euro 5	Euro 5	Euro 5
BV2	Euro 10	Euro 10	Euro 10
BV3	Euro 20	Euro 20	Euro 20
BV4	Euro 50	Euro 50	Euro 50
BV5	Euro 100	Euro 100	Euro 100
BV6	Euro 200	Euro 200	Euro 200