



EUR4

NE77 DIP SWITCHES SETTING : (Pulse/Parallel A4)

Supported bill EUR 5, 10, 20, 50

4bills.

DIP SWITCHES SETTING : (Parallel A4)

	FUNCTION	SW1	SW2	SW3	SW4	SW5	SW6	SW7	SW8	SW9	SW10
★	With Escow Function	ON									
	No Escow Function	OFF									
	Reserved		ON								
★	Reserved		OFF								
	Reserved			ON							
★	Reserved			OFF							
	Reserved				ON						
★	Reserved				OFF						
	Reserved					ON					
★	Reserved					OFF					
	Optical anti-fishing malfunction, BA will be still in working order					ON					
★	BA will stop to work when it acknowledges Optical anti-fishing malfunction					OFF					
★	Accept EUR 5 & 10						ON				
	Reject EUR 5 & 10						OFF				
★	Accept EUR 20 & 50							ON			
	Reject EUR 20 & 50							OFF			
★	Operation Mode								ON		
	Diagnostic Mode								OFF		
	Pulse Protocol									ON	
★	Parallel A4 Protocol									OFF	

★ Manufacture setting

Note: Please restart the bill acceptor after any changes on dip switch(s) has been made.

NE77-EUR4(Pulse/Parallel A4)

DIP SWITCHES SETTING : (Pulse)

	FUNCTION	SW1	SW2	SW3	SW4	SW5	SW6	SW7	SW8	SW9	SW10
★	1 Pulse / EUR 5	OFF	OFF	OFF							
	2 Pulses / EUR 5	OFF	OFF	ON							
	3 Pulses / EUR 5	OFF	ON	OFF							
	4 Pulses / EUR 5	OFF	ON	ON							
	5 Pulses / EUR 5	ON	OFF	OFF							
	10 Pulses / EUR 5	ON	OFF	ON							
	20 Pulses / EUR 5	ON	ON	OFF							
	100 Pulses / EUR 5	ON	ON	ON							
	Fast output Pulse Lo= 50ms Hi=100ms				ON						
★	Slow output Pulse Lo= 50ms Hi=300ms				OFF						
	Inhibit level Active Low					ON					
★	Inhibit level Active High					OFF					
★	Optical anti-fishing malfunction, BA will be still in working order						ON				
	BA will stop to work when it acknowledges Optical anti-fishing malfunction						OFF				
★	Accept EUR 5 & 10							ON			
	Reject EUR 5 & 10							OFF			
★	Accept EUR 20 & 50								ON		
	Reject EUR 20 & 50								OFF		
★	Operation Mode									ON	
	Diagnostic Mode									OFF	
★	Pulse Protocol										ON
	Parallel A4 Protocol										OFF

★ Manufacture setting