

NE77-EUR6

NE77 DIP SWITCHES SETTING : (Pulse/Parallel A4/RS232 A0)

Supported bill Euro 5, 10, 20, 50, 100, 200 6bills.

DIP SWITCHES SETTING : (Parallel A4)

	FUNCTION	SW1	SW2	SW3	SW4	SW5	SW6	SW7	SW8	SW9	SW10
	WITH ESCOW FUNCTION	ON									
★	NO ESCOW FUNCTION	OFF									
	RS232 A0 Potocol		ON								
★	Parallel A4 Potocol		OFF								
	Reserved			ON							
★	Reserved			OFF							
★	Enable Output Sensor Detect	(★★)			ON						
	Disable Output Sensor Detect	(★★)			OFF						
	Reserved				ON						
★	Reserved				OFF						
	Optical anti-fishing malfunction, BA will be still in working order	(★★★)				ON					
★	BA will stop to work when it acknowledges Optical anti-fishing malfunction	(★★★)				OFF					
	EUR 5 & 10 & 20							OFF	OFF		
★	EUR 5 & 10 & 20 & 50							OFF	ON		
	EUR 10 & 20 & 50 & 100							ON	OFF		
	EUR 10 & 20 & 50 & 100 & 200							ON	ON		
	Disable Bill Reject 4 Times BA Stop By 30 Sec									ON	
★	Enable Bill Reject 4 Times BA Stop By 30 Sec									OFF	
	Pulse Protocol										ON
★	Other Protocol										OFF

★ Manufacture setting

★★ ON: Autocheck motor reversal.

OFF: When output or hook is triggered in power on, error message displays three red, until after trouble clearing into autocheck.

★★★ ON: (1) After accepted banknotes through output sensor, if detect output trigger again, display sensor problem.

(2) After accepted banknote didn't leave output sensor, display sensor problem.

OFF: (1) After accepted banknotes through output sensor, if detect output trigger again, display sensor problem.

(2) After accepted banknote didn't leave output sensor, return to the idle.

Note: Please restart the bill acceptor after any changes on dip switch(s) has been made.

NE77 -EUR6 (Pulse/Parallel A4/RS232 A0)

DIP SWITCHES SETTING : (Pulse)

	FUNCTION	SW1	SW2	SW3	SW4	SW5	SW6	SW7	SW8	SW9	SW10
	5 Pulses / Euro 5	ON									
★	1 Pulse / Euro 5	OFF									
★	Lo=150ms / Hi=180ms		OFF	OFF							
	Lo= 50ms / Hi= 50 ms		OFF	ON							
	Lo= 80ms / Hi=120ms		ON	OFF							
	Lo= 50ms / Hi=300ms		ON	ON							
★	Enable Output Sensor Detect	(★★)			ON						
	Disable Output Sensor Detect	(★★)			OFF						
	Inhibit level Active Low					ON					
★	Inhibit level Active High					OFF					
	Optical anti-fishing malfunction, BA will be still in working order	(★★★)				ON					
★	BA will stop to work when it acknowledges Optical anti-fishing malfunction	(★★★)				OFF					
	EUR 5 & 10 & 20							OFF	OFF		
★	EUR 5 & 10 & 20 & 50							OFF	ON		
	EUR 10 & 20 & 50 & 100							ON	OFF		
	EUR 10 & 20 & 50 & 100 & 200							ON	ON		
	Disable Bill Reject 4 Times BA Stop By 30 Sec									ON	
★	Enable Bill Reject 4 Times BA Stop By 30 Sec									OFF	
★	Pulse Protocol										ON
	Other Protocol										OFF

DIP SWITCHES SETTING : (RS232 A0)

	FUNCTION	SW1	SW2	SW3	SW4	SW5	SW6	SW7	SW8	SW9	SW10
	Reserved	ON									
★	Reserved	OFF									
★	RS232 A0 Protocol		ON								
	Parallel A4 Protocol		OFF								
	Reserve			ON							
★	Reserve			OFF							
★	Enable Output Sensor Detect	(★★)			ON						
	Disable Output Sensor Detect	(★★)			OFF						
	Reserve				ON						
★	Reserve				OFF						
	Optical anti-fishing malfunction, BA will be still in working order	(★★★)				ON					
★	BA will stop to work when it acknowledges Optical anti-fishing malfunction	(★★★)				OFF					
	EUR 5 & 10 & 20							OFF	OFF		
★	EUR 5 & 10 & 20 & 50							OFF	ON		
	EUR 10 & 20 & 50 & 100							ON	OFF		
	EUR 10 & 20 & 50 & 100 & 200							ON	ON		
	Disable Bill Reject 4 Times BA Stop By 30 Sec									ON	
★	Enable Bill Reject 4 Times BA Stop By 30 Sec									OFF	
	Pulse Protocol										ON
★	Other Protocol										OFF

RS232 A0 INFORMATION

BillType Data	
Code	Denomination
1	Reserved
2	EUR 5
3	EUR 10
4	EUR 20
5	EUR 50
6	EUR 100
7	EUR 200