

KRW3

NK77/P2/P5 DIP SWITCHES SETTING : (Pulse/ICT)

Supported bill ₩ 1000, 5000, 10000 3bills.

FUNCTION	SW1	SW2	SW3	SW4	SW5	SW6	SW7	SW8	SW9	SW10
Special one pulse mode (Note 1)	OFF	OFF	OFF	OFF						
★ 1 Pulse / ₩1000	ON	OFF	OFF	OFF						
2 Pulse / ₩1000	OFF	ON	OFF	OFF						
3 Pulse / ₩1000	ON	ON	OFF	OFF						
4 Pulse / ₩1000	OFF	OFF	ON	OFF						
5 Pulse / ₩1000	ON	OFF	ON	OFF						
6 Pulse / ₩1000	OFF	ON	ON	OFF						
7 Pulse / ₩1000	ON	ON	ON	OFF						
8 Pulse / ₩1000	OFF	OFF	OFF	ON						
9 Pulse / ₩1000	ON	OFF	OFF	ON						
10 Pulse / ₩1000	OFF	ON	OFF	ON						
11 Pulse / ₩1000	ON	ON	OFF	ON						
12 Pulse / ₩1000	OFF	OFF	ON	ON						
13 Pulse / ₩1000	ON	OFF	ON	ON						
14 Pulse / ₩1000	OFF	ON	ON	ON						
15 Pulse / ₩1000	ON	ON	ON	ON						
★ Accept ₩ 1000					ON					
Reject ₩ 1000					OFF					
★ Accept ₩ 5000							ON			
Reject ₩ 5000							OFF			
★ Accept ₩ 10000								ON		
Reject ₩ 10000								OFF		
Fast output Pulse Lo= 50ms Hi=100ms								ON		
★ Slow output Pulse Lo=100ms Hi=200ms								OFF		
★ Pulse Mode										ON
ICT Mode										OFF
Manufacture Default										ON
★ System Default										OFF

(★) Manufacture setting

Note : Please reset the bill acceptor after set the dip switch.

(Note 1) : 1 PULSE/ 1000 KRW

1 PULSE/ 5000 KRW

1 PULSE/10000 KRW

In mode, only one dipswitch (SW5/SW6/SW7) can be on; otherwise, banknotes will be rejected.

