

A7/V7 PLUS-COP6

A7/V7 PLUS Option Switch Settings: 1

Supported bill Col\$ 1000(01, 05), 2000(96, 05), 5000(95),
10000(95), 20000(96), 50000(00) 6bills.

A7/V7 PLUS dip-switch settings and functions:

FUNCTION	SW1	SW2	SW3	SW4	SW5	SW6	SW7	SW8	SW1	SW2	SW3	SW4
Reject Col\$ 1000 & 2000	ON											
Accept Col\$ 1000 & 2000	OFF											
Reject Col\$ 5000		ON										
Accept Col\$ 5000		OFF										
Reject Col\$ 10000			ON									
Accept Col\$ 10000			OFF									
Reject Col\$ 20000				ON								
Accept Col\$ 20000				OFF								
Reject Col\$ 50000					ON							
Accept Col\$ 50000					OFF							
Ignore Sensor Problem(Note 1)						ON						
Acknowledge Sensor Problem (Note 2)						OFF						
Harness Disable							ON					
Harness Enable							OFF					
Inhibit Active High								ON				
Inhibit Active Low								OFF				
1 pulse / Col\$ 1000									OFF	OFF		
2 pulse / Col\$ 1000									ON	OFF		
4 pulse / Col\$ 1000									OFF	ON		
20 pulse / Col\$ 1000									ON	ON		
Pulse Speed	50ms on / 50ms off								OFF	OFF		
	60ms on / 300ms off								ON	OFF		
	30ms on / 50ms off								OFF	ON		
	150ms on / 150ms off								ON	ON		

◆ Factory configuration has all switches in the OFF position.

Note : (1) Reset the bill acceptor after setting the dip switch.

(2) SW7 and SW8 of the 8-switch DIP and the 4-switch DIP are for pulse protocol only.

◆ (Note 1) Sensor 3 problem occurred ==>> BA will be still in working order.

(The face LED will be flashing in short green about 2 seconds everytime you restart BA.)

(Note 2) BA will stop to work when it acknowledges Sensor 3 problem occurred.

(The face LED will be flashing in red.)

A7 PLUS Interface Settings: 2

INTERFACE	SW2	SW3
Pulse	ON	ON
NISR	OFF	ON
RS232	ON	OFF
5V Enable	OFF	OFF

V7 PLUS Interface Settings: 3

INTERFACE	SW2	SW3	SW4
Pulse	ON	ON	
MDB	OFF	ON	
RS232	ON	OFF	
Credit Converting Mode 1 (Note.A)			ON
Credit Converting Mode 2 (Note.B)			OFF

- ◆ Remove the front cover and the dip-switch is on the CPU board.
(Note. A) Mode 1: To output the credit which is the same as the input bill.
(for M.D.B. only)
 - (Note. B) Mode 2: To output the credit which is 1/10 of the input bill.
(for M.D.B. only)
- This is a special version of BA for the local vending machine in CNY.