

S7ER-THB4 Option Switch Settings: (ICT)

Supported bill THB 20, 50, 100, 500

4bills.

S7ER dip-switch settings and functions:

FUNCTION	SW1	SW2	SW3	SW4	SW5	SW6	SW7	SW8	SW1	SW2	SW3	SW4	SW1	SW2	SW3	SW4
★ Reject THB 20	ON															
★ Accept THB 20	OFF															
★ Reject THB 50		ON														
★ Accept THB 50		OFF														
★ Reject THB 100			ON													
★ Accept THB 100			OFF													
★ Reject THB 500				ON												
★ Accept THB 500				OFF												
★ Reserved					ON											
★ Reserved					OFF											
★ Disable Bill Reject 4 Times BA Stop By 30 Sec						ON										
★ Enable Bill Reject 4 Times BA Stop By 30 Sec						OFF										
★ Stack Banknote when Power-up							ON									
★ Reject Banknote when Power-up							OFF									
★ Test Mode								ON								
★ Reserved								OFF								
★ Pulse Speed	100ms on / 100ms off								ON							
	50ms on / 50ms off								OFF							
★ ENABLE INHIBIT-Sleep only										ON						
★ 5 second Timeout only										OFF						
★ Normal										OFF	OFF					
★ Mode 1										OFF	ON					
★ Mode 2										ON	OFF					
★ Mode 1 + 2										ON	ON					
★ Reserved												ON				
★ Reserved												OFF				
★ Pulse Mode														ON		
★ ICT Mode														OFF		
★ Reserved															OFF	OFF
★ Reserved															OFF	ON
★ Reserved															ON	OFF
★ Reserved															ON	ON

★ Manufacture setting

Note: 1. After setting dip switch of the credit pulses, you should reset the bill acceptor again.

2. Normal : No sleep function.

3. Mode 1 : Bill-acceptor wakes up VMC with banknote only (special cable required).

4. Mode 2 : VMC wakes up bill-acceptor.

5. Mode 1+2 : Bill-acceptor wakes up with banknote or by VMC.

