

S7ER-ZAR4 Option Switch Settings: (Pulse)

Supported bill R 10, 20, 50, 100

4bills.

S7ER dip-switch settings and functions:

FUNCTION	SW1	SW2	SW3	SW4	SW5	SW6	SW7	SW8	SW1	SW2	SW3	SW4	SW1	SW2	SW3	SW4
★ Reject R 10	ON															
★ Accept R 10	OFF															
★ Reject R 20		ON														
★ Accept R 20		OFF														
★ Reject R 50			ON													
★ Accept R 50			OFF													
★ Reject R 100				ON												
★ Accept R 100				OFF												
★ Reserved					ON											
★ Reserved					OFF											
★ Disable Bill Reject 4 Times BA Stop By 30 Sec						ON										
★ Enable Bill Reject 4 Times BA Stop By 30 Sec						OFF										
★ Stack Banknote when Power-up							ON									
★ Reject Banknote when Power-up							OFF									
★ Inhibit Active HIGH								ON								
★ Inhibit Active LOW								OFF								
★ Pulse Speed	100ms on / 100ms off								ON							
	50ms on / 50ms off								OFF							
★ ENABLE INHIBIT-Sleep only										ON						
★ 5 second Timeout only										OFF						
★ Normal											OFF	OFF				
★ Mode 1											OFF	ON				
★ Mode 2											ON	OFF				
★ Mode 1 + 2											ON	ON				
★ Credit-Pulse Normal HIGH													ON			
★ Credit-Pulse Normal LOW													OFF			
★ Pulse Mode														ON		
★ ICT Mode														OFF		
★ 1 pulse / R 10															OFF	OFF
★ 5 pulses / R 10															OFF	ON
★ 10 pulses / R 10															ON	OFF
★ 25 pulses / R 10															ON	ON

★ Manufacture setting

Note: 1. After setting dip switch of the credit pulses, you should reset the bill acceptor again.

2. Normal : No sleep function.

3. Mode 1 : Bill-acceptor wakes up VMC with banknote only (special cable required).

4. Mode 2 : VMC wakes up bill-acceptor.

5. Mode 1+2 : Bill-acceptor wakes up with banknote or by VMC.

