

XBA mini-MDL9

XBA mini Option Switch Settings: 1(Pulse/MDB/JPSTD/ICT104V/ICT104U)

Supported bill MDL 1, 5, 10, 20, 50, 100, 200, 500, 1000 9bills.

XBA mini dip-switch settings and functions:

	FUNCTION	SW1	SW2	SW3	SW4	SW5	SW6	SW7	SW8	SW1	SW2	SW3	SW4
★	Reject MDL 1 (NOTE2)	ON											
★	Accept MDL 1 (NOTE2)	OFF											
★	Reject MDL 5 & 10 & 20		ON										
★	Accept MDL 5 & 10 & 20		OFF										
★	Reject MDL 50 & 100 & 200			ON									
★	Accept MDL 50 & 100 & 200			OFF									
★	Reject MDL 500				ON								
★	Accept MDL 500				OFF								
★	Reject MDL 1000					ON							
★	Accept MDL 1000					OFF							
★	Disable Bill Reject 4 Times BA Stop By 30 Sec					ON							
★	Enable Bill Reject 4 Times BA Stop By 30 Sec					OFF							
★	Stack Banknote when Power-up							ON					
★	Reject Banknote when Power-up							OFF					
★	Reserved								ON				
★	Reserved								OFF				
★	Inhibit Active High								ON				
★	Inhibit Active Low								OFF				
★	Reserved									ON			
★	Reserved									OFF			
★	Interface Timing Conversion	50ms LO / 50ms HI								OFF		OFF	
		60ms LO / 300ms HI								ON		OFF	
		30ms LO / 50ms HI								OFF		ON	
		150ms LO / 150ms HI								ON		ON	

★ Manufacture setting

After setting dip switch of the credit pulses, you should reset the bill acceptor again.

Note : (1) Calibration card is needed

(2) Dip 1 turn OFF (Pulse Mode:1 Pulse/1 MDL ,MDB Mode:Reject MDL 500 & 1000)

Dip 1 turn ON (Pulse Mode:1 Pulse/5 MDL ,MDB Mode:Accept MDL 500 & 1000)

XBA mini-MDL9(Pulse/MDB/JPSTD/ICT104V/ICT104U)

Interface Settings: 2(Pulse)

	INTERFACE	SW1	SW2	SW3	SW4
★	Credit-Pulse Normal HIGH	ON			
	Credit-Pulse Normal LOW	OFF			
★	Pulse Mode		ON		
	Other Mode		OFF		
★	1 pulse / MDL 1 & 5 (NOTE2)			OFF	OFF
	2 pulses / MDL 1 & 5 (NOTE2)			OFF	ON
	5 pulses / MDL 1 & 5 (NOTE2)			ON	OFF
	10 pulses / MDL 1 & 5 (NOTE2)			ON	ON

★ Manufacture setting

Interface Settings: 2(Other)

	INTERFACE	SW1	SW2	SW3	SW4
★	Reserved	ON			
	Reserved	OFF			
	Pulse Mode		ON		
★	Other Mode		OFF		
	MDB Mode			OFF	OFF
	JPSTD Mode			OFF	ON
	ICT104U Mode			ON	OFF
	ICT104V Mode			ON	ON

★ Manufacture setting

Interface Settings: 2(ICT104V)

	INTERFACE	SW1	SW2	SW3	SW4
★	Connect with coin changer	ON			
	Connect with ICT JPSTD converter board	OFF			
	Pulse Mode		ON		
★	Other Mode		OFF		
	MDB Mode			OFF	OFF
	JPSTD Mode			OFF	ON
	ICT104U Mode			ON	OFF
★	ICT104V Mode			ON	ON

★ Manufacture setting

Interface Settings: 2(MDB)

	FUNCTION	SW1	SW2	SW3	SW4
★	Scaling Factor (SF) = 100 Decimal Point Position (DPP) = 2	ON			
	Scaling Factor (SF) = 1 Decimal Point Position (DPP) = 0	OFF			
	Pulse Mode		ON		
★	Other Mode		OFF		
★	MDB Mode			OFF	OFF
	JPSTD Mode			OFF	ON
	ICT104U Mode			ON	OFF
	ICT104V Mode			ON	ON

★ Manufacture setting

Currency Assign Data

Dip 1 is OFF					
Interface Bill value	Pulse	MDB	ICT104U	ICT104V	JPSTD
BV1	1	1	1	1	1
BV2	5	5	5	5	
BV3	10	10	10	10	
BV4	20	20	20	20	
BV5	50	50	50	50	
BV6	100	100	100	100	
BV7	200	200	200	200	
BV8	500		500	500	
BV9	1000		1000	1000	
Dip 1 is ON					
Interface Bill value	Pulse	MDB	ICT104U	ICT104V	JPSTD
BV1		5			
BV2	5	10	5	5	
BV3	10	20	10	10	
BV4	20	50	20	20	
BV5	50	100	50	50	
BV6	100	200	100	100	
BV7	200	500	200	200	
BV8	500	1000	500	500	
BV9	1000		1000	1000	