

XBA mini-PKR7

XBA mini Option Switch Settings: 1(Pulse/MDB/JPSTD/ICT104U/ICT104V)

Supported bill PKR 10, 20, 50, 100, 500, 1000, 5000 7bills.

XBA mini dip-switch settings and functions:

FUNCTION	SW1	SW2	SW3	SW4	SW5	SW6	SW7	SW8	SW1	SW2	SW3	SW4
★ Reject PKR 10 & 20 (Note.3)	ON											
★ Accept PKR 10 & 20 (Note.3)	OFF											
★ Reject PKR 50 & 100		ON										
★ Accept PKR 50 & 100		OFF										
★ Reject PKR 500			ON									
★ Accept PKR 500			OFF									
★ Reject PKR 1000				ON								
★ Accept PKR 1000				OFF								
★ Reject PKR 5000					ON							
★ Accept PKR 5000					OFF							
★ Disable Bill Reject 4 Times BA Stop By 30 Sec						ON						
★ Enable Bill Reject 4 Times BA Stop By 30 Sec						OFF						
★ Stack Banknote when Power-up							ON					
★ Reject Banknote when Power-up							OFF					
★ Reserved								ON				
★ Reserved								OFF				
★ Inhibit Active High									ON			
★ Inhibit Active Low									OFF			
★ Reserved										ON		
★ Reserved										OFF		
★ Interface Timing Conversion		50ms LO / 50ms HI									OFF	OFF
		60ms LO / 300ms HI									ON	OFF
		30ms LO / 50ms HI									OFF	ON
		150ms LO / 150ms HI									ON	ON

★ Manufacture setting

After setting dip switch of the credit pulses, you should reset the bill acceptor again.

Note : (1) Please reset the bill acceptor after set the dip switch.

(2) Calibration card is needed.

(3) ** MDB Mode:

When Dip 1 is OFF, Reject PKR 5000.

When Dip 1 is ON, Accept PKR 5000.

XBA mini-PKR7(Pulse/MDB/JPSTD/ICT104V/ICT104U)

Interface Settings: 2(Pulse)

INTERFACE	SW1	SW2	SW3	SW4
★ Credit-Pulse Normal HIGH	ON			
Credit-Pulse Normal LOW	OFF			
★ Pulse Mode		ON		
Other Mode		OFF		
★ 1 pulse / PKR 10			OFF	OFF
5 pulses / PKR 10			OFF	ON
10 pulses / PKR 10			ON	OFF
20 pulses / PKR 10			ON	ON

★ Manufacture setting

Interface Settings: 2(MDB)

FUNCTION	SW1	SW2	SW3	SW4
★ Scaling Factor (SF) = 100	ON			
Decimal Point Position (DPP) = 2				
Scaling Factor (SF) = 1	OFF			
Decimal Point Position (DPP) = 0				
Pulse Mode		ON		
Other Mode		OFF		
★ MDB Mode			OFF	OFF
JPSTD Mode			OFF	ON
ICT104U Mode			ON	OFF
ICT104V Mode			ON	ON

★ Manufacture setting

Interface Settings: 2(Other)

FUNCTION	SW1	SW2	SW3	SW4
★ Reserved	ON			
Reserved	OFF			
Pulse Mode		ON		
Other Mode		OFF		
MDB Mode			OFF	OFF
JPSTD Mode			OFF	ON
ICT104U Mode			ON	OFF
ICT104V Mode			ON	ON

★ Manufacture setting

Interface Settings: 2(ICT104V)

FUNCTION	SW1	SW2	SW3	SW4
★ Connect with coin changer	ON			
Connect with ICT JPSTD Converter board	OFF			
Pulse Mode		ON		
Other Mode		OFF		
MDB Mode			OFF	OFF
JPSTD Mode			OFF	ON
ICT104U Mode			ON	OFF
★ ICT104V Mode			ON	ON

★ Manufacture setting

Currency Assign Data

Interface	JPSTD	ICT104U	ICT104V	Pulse	MDB	
Bill value					When Dip 1 is OFF	When Dip 1 is ON
BV1	PKR 10	PKR 10	PKR 10	PKR 10	PKR 10	
BV2		PKR 20	PKR 20	PKR 20	PKR 20	
BV3		PKR 50	PKR 50	PKR 50	PKR 50	PKR 50
BV4		PKR 100	PKR 100	PKR 100	PKR 100	PKR 100
BV5		PKR 500	PKR 500	PKR 500	PKR 500	PKR 500
BV6		PKR 1000	PKR 1000	PKR 1000	PKR 1000	PKR 1000
BV7		PKR 5000	PKR 5000	PKR 5000		PKR 5000