

Supported bill LKR 100, 500

2 bills.

		_		_	_			_		_	_
	FUNCTION	SW1	SW2	SW3	SW4	SW5	SW6	SW7	SW8	SW9	SW10
*	1 Pulse / RUPEES 100	OFF	OFF	OFF							
	2 Pulse / RUPEES 100	OFF	OFF	ON							
	3 Pulse / RUPEES 100	OFF	ON	OFF							
	4 Pulse / RUPEES 100	OFF	ON	ON							
	5 Pulse / RUPEES 100	ON	OFF	OFF							
	10 Pulse / RUPEES 100	ON	OFF	ON							
	20 Pulse / RUPEES 100	ON	ON	OFF							
	100 Pulse / RUPEES 100	ON	ON	ON							
	Fast output Pulse Lo= 50ms Hi=100ms				ON						
*	Slow output Pulse Lo= 50ms Hi=300ms				OFF						
	Inhibit level Active Low					ON					
*	Inhibit level Active High					OFF					
*	Accept RUPEES 100						ON				
	Reject RUPEES 100						OFF				
*	Accept RUPEES 500							ON			
	Reject RUPEES 500							OFF			
*	Reserved								ON		
	Reserved								OFF		
	Reserved									ON	
*	Reserved									OFF	
	Reserved										ON
*	Reserved		•	•				•			OFF

[★] Manufacture setting

Note: (1) Please reset the bill acceptor after set the dip switch.

(2) Dip switches 1 to 5 are only used for pulse protocol.

DIP SWITCHES SETTING: 2

	FUNCTION	SW1	SW2	SW3	SW4	
*	Credit - Pulse Normal High					
	Credit - Pulse Normal Low	OFF				
*	Pulse Mode		ON			
	ICT Mode		OFF			
*	Reserved			ON		
				OFF		
*						

© 2012 International Currency Technologies Corporation V. 1.0 Part Number : SWC4LK210-R