

L70-PEN4

L70/P5 DIP SWITCHES SETTING : 1(Pulse/RS232 A0/Parallel A1)

Supported bill soles 10, 20, 50, 100 4 bills.

FUNCTION	SW1	SW2	SW3	SW4	SW5	SW6	SW7	SW8	SW9	SW10
★ 1 Pulse / soles 10	OFF	OFF	OFF							
2 Pulses / soles 10	OFF	OFF	ON							
3 Pulses / soles 10	OFF	ON	OFF							
4 Pulses / soles 10	OFF	ON	ON							
5 Pulses / soles 10	ON	OFF	OFF							
10 Pulses / soles 10	ON	OFF	ON							
20 Pulses / soles 10	ON	ON	OFF							
100 Pulses / soles 10	ON	ON	ON							
Fast output Pulse Lo= 50ms Hi=100ms				ON						
★ Slow output Pulse Lo= 50ms Hi=300ms				OFF						
Inhibit level Active Low					ON					
★ Inhibit level Active High					OFF					
★ Accept soles 10						ON				
Reject soles 10						OFF				
★ Accept soles 20							ON			
Reject soles 20							OFF			
★ Accept soles 50								ON		
Reject soles 50								OFF		
★ Accept soles 100									ON	
Reject soles 100									OFF	
★ Reserve										ON
★ Reserve										OFF

★ Manufacture setting

Note: (1) Please reset the bill acceptor after set the dip switch.

(2) Dip switches 1 to 5 are only used for pulse protocol.

L70-PEN4/P5(Pulse/RS232 A0/Parallel A1)

DIP SWITCHES SETTING : 2(Pulse)

FUNCTION	SW1	SW2	SW3	SW4
★ Pulse Normal High	ON			
Pulse Normal Low	OFF			
★ Pulse Mode		ON	OFF	
Parallel A1 Mode		OFF	ON	
RS232 A0 Mode		OFF	OFF	
Reserved		ON	ON	
Reserved				ON
★ Reserved				OFF

★ Manufacture setting

DIP SWITCHES SETTING : 2(Parallel A1)

FUNCTION	SW1	SW2	SW3	SW4
★ Reserved	ON			
Reserved	OFF			
Pulse Mode		ON	OFF	
★ Parallel A1 Mode		OFF	ON	
RS232 A0 Mode		OFF	OFF	
Reserved		ON	ON	
Reserved				ON
★ Reserved				OFF

★ Manufacture setting

DIP SWITCHES SETTING : 2(RS232 A0)

FUNCTION	SW1	SW2	SW3	SW4
★ Reserved	ON			
Reserved	OFF			
Pulse Mode		ON	OFF	
Parallel A1 Mode		OFF	ON	
★ RS232 A0 Mode		OFF	OFF	
Reserved		ON	ON	
Reserved				ON
★ Reserved				OFF

★ Manufacture setting

Currency Assign Data

Interface Bill value	Parallel A1	RS232 A0	Pulse
BV1	soles 10	soles 10	soles 10
BV2	soles 20	soles 20	soles 20
BV3	soles 50	soles 50	soles 50
BV4	soles 100	soles 100	soles 100

RS232 A0 INFORMATION

BillType Data	
Code	Denomination
1	Soles 10
2	Soles 20
3	Soles 50
4	Soles 100
5	Reserved
6	Reserved
7	Reserved
8	Reserved
9	Reserved