

COP6

P70/P5 DIP SWITCHES SETTING : 1(Pulse/RS232 A0)

Supported bill Col\$ 1000, 2000, 5000, 10000, 20000, 50000(00) 6bills.

	FUNCTION	SW1	SW2	SW3	SW4	SW5	SW6	SW7	SW8	SW9	SW10
★	1 Pulse / 1000 pesos	OFF	OFF	OFF							
	2 Pulses / 1000 pesos	OFF	OFF	ON							
	3 Pulses / 1000 pesos	OFF	ON	OFF							
	4 Pulses / 1000 pesos	OFF	ON	ON							
	5 Pulses / 1000 pesos	ON	OFF	OFF							
	10 Pulses / 1000 pesos	ON	OFF	ON							
	20 Pulses / 1000 pesos	ON	ON	OFF							
	100 Pulses / 1000 pesos	ON	ON	ON							
	Fast output Pulse Lo= 50ms Hi=100ms				ON						
★	Slow output Pulse Lo= 50ms Hi=300ms				OFF						
	Inhibit level Active Low				ON						
★	Inhibit level Active High				OFF						
★	Accept Col\$ 1000 & 2000				ON						
	Reject Col\$ 1000 & 2000				OFF						
★	Accept Col\$ 5000				ON						
	Reject Col\$ 5000				OFF						
★	Accept Col\$ 10000				ON						
	Reject Col\$ 10000				OFF						
★	Accept Col\$ 20000				ON						
	Reject Col\$ 20000				OFF						
★	Accept Col\$ 50000				ON						
	Reject Col\$ 50000				OFF						

★ Manufacture setting

Note: (1)Please reset the bill acceptor after set the dip switch.

(2)Dip switches 1 to 5 are only used for pulse protocol.

DIP SWITCHES SETTING : 2

	FUNCTION	SW1	SW2	SW3	SW4
★	Credit-Pulse Normal HIGH	ON			
	Credit-Pulse Normal LOW	OFF			
★	Pulse Mode		ON		
	RS232 A0 Interface		OFF		
	Harness Disable			ON	
★	Harness Enable			OFF	
	Ignore Sensor Problem(Note 1)				ON
★	Acknowledge Sensor Problem (Note 2)				OFF

★ Manufacture setting

Note : (1) Sensor 6 problem occurred ==> BA will be still in working order.

(The face LED will be flashing in short green about 2 seconds everytime you restart BA.)

(2) BA will stop to work when it acknowledges Sensor 6 problem occurred.

(The face LED will be flashing in red.)