

P85-EUR6

P85/P5 DIP SWITCHES SETTING : 1(Pulse/ccTalk)

Supported bill Euro 5, 10, 20, 50, 100, 200 6bills.

FUNCTION	SW1	SW2	SW3	SW4	SW5	SW6	SW7	SW8	SW9	SW10
★ 1 Pulse / Euro 5	OFF	OFF	OFF							
2 Pulse / Euro 5	OFF	OFF	ON							
3 Pulse / Euro 5	OFF	ON	OFF							
4 Pulse / Euro 5	OFF	ON	ON							
5 Pulse / Euro 5	ON	OFF	OFF							
10 Pulse / Euro 5	ON	OFF	ON							
20 Pulse / Euro 5	ON	ON	OFF							
100 Pulse / Euro 5	ON	ON	ON							
Fast output Pulse Lo= 50ms Hi= 100ms					ON					
★ Slow output Pulse Lo= 50ms Hi= 300ms				OFF						
Inhibit level Active Low					ON					
★ Inhibit level Active High					OFF					
★ Accept Euro 5						ON				
Reject Euro 5						OFF				
★ Accept Euro 10 & 20							ON			
Reject Euro 10 & 20							OFF			
★ Accept Euro 50								ON		
Reject Euro 50								OFF		
★ Accept Euro 100 & 200									ON	
Reject Euro 100 & 200									OFF	
★ Accept Normal										ON
Reject Euro 5(2002) & 10(2002)										OFF

★ Manufacture setting

Note: (1) Please reset the bill acceptor after set the dip switch.
(2) Dip switches 1 to 5 are only used for pulse protocol.

P85-EUR6(Pulse/ccTalk)

DIP SWITCHES SETTING : 2(Pulse)

FUNCTION	SW1	SW2	SW3	SW4
★ Pulse Normal High	ON			
Pulse Normal Low	OFF			
★ Pulse Protocol		ON		
ccTalk Protocol		OFF		
Harness Disable			ON	
★ Harness Enable			OFF	
★ Reserved				ON
				OFF

★ Manufacture setting

DIP SWITCHES SETTING : 2(ccTalk)

FUNCTION	SW1	SW2	SW3	SW4
★ Encryption MODE	ON			
Decrypt MODE	OFF			
Pulse Protocol		ON		
★ ccTalk Protocol		OFF		
ccTalk Parameters Restore Switch Please see "Note" for detail			ON	
★ Keep ccTalk Parameters			OFF	
★ Reserved				ON
				OFF

★ Manufacture setting

Note : (1) Please reset the bill acceptor after set the dip switch.

(2) ccTalk Parameters Reset

Put this switch to on and reset power will restore the ccTalk address to its default value of 40 and the encryption key to its default value of 123456.

*This has to be done after finished calibration process.

Currency Assign Data

Interface Bill value	Pulse	ccTalk
BV1	Euro 5(2002)	Euro 5(2002)
BV2	Euro 10(2002)	Euro 10(2002)
BV3	Euro 20(2002)	Euro 20(2002)
BV4	Euro 50(2002)	Euro 50(2002)
BV5	Euro 100(2002)	Euro 100(2002)
BV6	Euro 200(2002)	Euro 200(2002)
BV7	Euro 5(2013)	Euro 5(2013)
BV8	Euro 10(2014)	Euro 10(2014)
BV9	Euro 20(2015)	Euro 20(2015)
BV10	Euro 50(2017)	Euro 50(2017)
BV11	Euro 100(2019)	Euro 100(2019)
BV12	Euro 200(2019)	Euro 200(2019)