

# TAO-A-MXN5+USD4

## TAO-A Option Switch Settings: 1(Pulse/NISR/ICT002U/5V Enable/Out of Service)

Supported bill **MXN 20, 50, 100, 200, 500**  
**USD 1, 5, 10, 20** **9bills.**

TAO-A dip-switch settings and functions:

	FUNCTION	SW1	SW2	SW3	SW4	SW5	SW6	SW7	SW8	SW1	SW2	SW3	SW4
★	Reject MXN 20 & USD 1	ON											
★	Accept MXN 20 & USD 1	OFF											
	Reject MXN 50 & USD 5		ON										
★	Accept MXN 50 & USD 5		OFF										
	Reject MXN 100 & USD 10			ON									
★	Accept MXN 100 & USD 10			OFF									
	Reject MXN 200.500 & USD 20				ON								
★	Accept MXN 200.500 & USD 20				OFF								
	Accept Mexico Pesos and US Dollars (Note 3)					ON							
★	Accept Mexico Pesos Only (Note 3)					OFF							
	Reserved						ON						
★	Reserved						OFF						
	Harness Disable							ON					
★	Harness Enable							OFF					
	Inhibit Active High								ON				
★	Inhibit Active Low								OFF				
★	1 pulse / MXN 10 & USD 1									OFF	OFF		
	2 pulses / MXN 10 & USD 1									ON	OFF		
	5 pulses / MXN 10 & USD 1									OFF	ON		
	10 pulses / MXN 10 & USD 1									ON	ON		
★	Interface Timing Conversion	50ms LO / 50ms HI								OFF	OFF		
		60ms LO / 300ms HI								ON	OFF		
		30ms LO / 50ms HI								OFF	ON		
		150ms LO / 150ms HI								ON	ON		

★ Manufacture setting

Note : (1) Default setting.

(2) Use 2nd dip switch of the internal dip-switch to change different interface protocol.

(3) For Accepting US Dollars, make sure you have dip 5 set to ON position.

(\* Exchange Rate on USD to MXN is 1:10)

# TAO-A-MXN5+USD4(Pulse/NISR/ICT002U/5V Ebable/Out of Service)

## Interface Settings: 2(ICT002U)

	INTERFACE	SW1	SW2	SW3	SW4
★	Reserved	ON			
		OFF			
★	ICT002U Mode		ON	ON	
	NISR Mode		OFF	ON	
	Pulse Mode		ON	OFF	
	5V Enable Mode		OFF	OFF	
★	Reserved				ON
					OFF

★ Manufacture setting

## Interface Settings: 2(Pulse)

	INTERFACE	SW1	SW2	SW3	SW4
★	Credit-Pulse Normal HIGH	ON			
	Credit-Pulse Normal LOW	OFF			
	ICT002U Mode		ON	ON	
	NISR Mode		OFF	ON	
★	Pulse Mode		ON	OFF	
	5V Enable Mode		OFF	OFF	
★	Reserved				ON
					OFF

★ Manufacture setting

## Interface Settings: 2(5V Enable)

	INTERFACE	SW1	SW2	SW3	SW4
★	Credit-Pulse Normal HIGH	ON			
	Credit-Pulse Normal LOW	OFF			
	ICT002U Mode		ON	ON	
	NISR Mode		OFF	ON	
	Pulse Mode		ON	OFF	
★	5V Enable Mode		OFF	OFF	
★	Reserved				ON
					OFF

★ Manufacture setting

## Interface Settings: 2(NISR)

	INTERFACE	SW1	SW2	SW3	SW4
★	Reserved	ON			
		OFF			
	ICT002U Mode		ON	ON	
★	NISR Mode		OFF	ON	
	Pulse Mode		ON	OFF	
	5V Enable Mode		OFF	OFF	
★	Reserved				ON
					OFF

★ Manufacture setting

## Currency Assign Data

Interface Bill value	5V Enable		Pulse	
BV1		USD 1		USD 1
BV2	MXN 20		MXN 20	
BV3	MXN 50		MXN 50	
BV4	MXN 100		MXN 100	
BV5	MXN 200		MXN 200	
BV6	MXN 500		MXN 500	
BV7		USD 5		USD 5
BV8		USD 10		USD 10
BV9		USD 20		USD 20

Interface Bill value	ICT002U		NISR	
BV1		USD 1		USD 1
BV2	MXN 20		MXN 20	
BV3	MXN 50		MXN 50	
BV4	MXN 100		MXN 100	
BV5	MXN 200		MXN 200	
BV6	MXN 500		MXN 500	
BV7		USD 5		USD 5
BV8		USD 10		USD 10
BV9		USD 20		USD 20