

TAO-A/V-PEN4

**TAO-A/V Option Switch Settings: 1(Pulse/RS232 A0)
Supported bill SOL 10, 20, 50, 100 4bills.**

TAO-A/V dip-switch settings and functions:

FUNCTION	SW1	SW2	SW3	SW4	SW5	SW6	SW7	SW8	SW1	SW2	SW3	SW4
★ Reject SOL 10	ON											
★ Accept SOL 10	OFF											
★ Reject SOL 20		ON										
★ Accept SOL 20		OFF										
★ Reject SOL 50			ON									
★ Accept SOL 50			OFF									
★ Reject SOL 100				ON								
★ Accept SOL 100				OFF								
★ Reserved					ON							
★ Reserved					OFF							
★ Reserved						ON						
★ Reserved						OFF						
★ Harness Disable							ON					
★ Harness Enable							OFF					
★ Inhibit Active High								ON				
★ Inhibit Active Low								OFF				
★ 1 pulse / SOL 10									OFF	OFF		
5 pulses / SOL 10									ON	OFF		
10 pulses / SOL 10									OFF	ON		
20 pulses / SOL 10									ON	ON		
★ Interface Timing Conversion			50ms on / 50ms off								OFF	OFF
			60ms on / 300ms off								ON	OFF
			30ms on / 50ms off								OFF	ON
			150ms on / 150ms off								ON	ON

★ Manufacture setting

◆ Note : (1) Reset the bill acceptor after setting the dip switch.

(2) SW7 and SW8 of the 8-switch DIP and the 4-switch DIP are for pulse protocol only.

TAO-A/V-PEN4(Pulse/RS232 A0)

Interface Settings: 2(Pulse)

INTERFACE	SW1	SW2	SW3	SW4
★ Credit-Pulse Normal HIGH	ON			
Credit-Pulse Normal LOW	OFF			
★ Pulse Mode		ON		
RS232 A0 Protocol		OFF		
★ Reserved			ON	
			OFF	
				ON
				OFF

★ Manufacture setting

Interface Settings: 3(RS232 A0)

INTERFACE	SW1	SW2	SW3	SW4
★ Reserved	ON			
	OFF			
Pulse Mode		ON		
★ RS232 A0 Interface		OFF		
★ Reserved			ON	
			OFF	
				ON
				OFF

★ Manufacture setting