

BS7-UAH6

BS7 Option Switch Settings: 1 (Pulse/MDB)

Supported bill UAH 1, 2, 5, 10, 20, 50 6bills.

BS7 dip-switch settings and functions:

| FUNCTION | SW1 | SW2 | SW3 | SW4 | SW5 | SW6 | SW7 | SW8 |
|------------------------|-----|-----|-----|-----|-----|-----|-----|-----|
| ★ Reject UAH 1 & 2 | ON | | | | | | | |
| ★ Accept UAH 1 & 2 | OFF | | | | | | | |
| ★ Reject UAH 5 | | ON | | | | | | |
| ★ Accept UAH 5 | | OFF | | | | | | |
| ★ Reject UAH 10 | | | ON | | | | | |
| ★ Accept UAH 10 | | | OFF | | | | | |
| ★ Reject UAH 20 | | | | ON | | | | |
| ★ Accept UAH 20 | | | | OFF | | | | |
| ★ Reject UAH 50 | | | | | ON | | | |
| ★ Accept UAH 50 | | | | | OFF | | | |
| ★ Reserved | | | | | | ON | | |
| ★ Reserved | | | | | | OFF | | |
| ★ Harness Disable | | | | | | | ON | |
| ★ Harness Engle | | | | | | | OFF | |
| ★ Inhiblit Active High | | | | | | | | ON |
| ★ Inhibit Active Low | | | | | | | | OFF |

◆ Factory configuration has all switches in the OFF position.

Interface Settings: 2(Pulse) Interface Settings: 3(Pulse)

| INTERFACE | SW1 | SW2 | SW3 | SW4 |
|----------------------|-----|-----|-----|-----|
| ★ 1 pulse / UAH 1 | OFF | OFF | | |
| 5 pulses / UAH 1 | ON | OFF | | |
| 10 pulses / UAH 1 | OFF | ON | | |
| 20 pulses / UAH 1 | ON | ON | | |
| ★ 50ms on / 50ms off | | | OFF | OFF |
| 60ms on / 300ms off | | | ON | OFF |
| 30ms on / 50ms off | | | OFF | ON |
| 150ms on / 150ms off | | | ON | ON |

★ Manufacture setting

| INTERFACE | SW1 | SW2 | SW3 | SW4 |
|----------------------------|-----|-----|-----|-----|
| ★ Credit-Pulse Normal High | ON | | | |
| Credit-Pulse Normal Low | OFF | | | |
| ★ Pulse Mode | | ON | | |
| MDB Interface | | OFF | | |
| ★ Reserved | | | ON | |
| ★ Reserved | | | OFF | |
| ★ Reserved | | | | ON |
| ★ Reserved | | | | OFF |

BS7-UAH6

BS7 Interface Settings: 2(MDB)

| INTERFACE | SW1 | SW2 | SW3 | SW4 |
|------------|-----|-----|-----|-----|
| ★ Reserved | ON | | | |
| ★ Reserved | OFF | | | |
| ★ Reserved | | ON | | |
| ★ Reserved | | OFF | | |
| ★ Reserved | | | ON | |
| ★ Reserved | | | OFF | |
| ★ Reserved | | | | ON |
| ★ Reserved | | | | OFF |

★ Manufacture setting

BS7 Interface Settings: 3(MDB)

| INTERFACE | SW1 | SW2 | SW3 | SW4 |
|---|-----|-----|-----|-----|
| ★ Scaling Factor (SF) = 100 Decimal Point Position (DPP) = 2 | ON | | | |
| Scaling Factor (SF) = 1 Decimal Point Position (DPP) = 0 | OFF | | | |
| Pulse Mode | | ON | | |
| ★ MDB Interface (Note) | | OFF | | |
| ★ Reserved | | | ON | |
| ★ Reserved | | | OFF | |
| ★ Reserved | | | | ON |
| ★ Reserved | | | | OFF |

★ Manufacture setting

Note: Please refer to the dip-switch #1 of internal dip-switch for MDB Decimal Point Setup.

Currency Assign Data

| Interface Bill value | Pulse | MDB |
|-------------------------|--------|--------|
| BV1 | UAH 1 | UAH 1 |
| BV2 | UAH 2 | UAH 2 |
| BV3 | UAH 5 | UAH 5 |
| BV4 | UAH 10 | UAH 10 |
| BV5 | UAH 20 | UAH 20 |
| BV6 | UAH 50 | UAH 50 |