

# UAH9

## L77&L77F DIP SWITCHES SETTING : 1(Pulse/ICT/RS232 A0)

Supported bill Hryven 1, 2, 5, 10, 20, 50, 100, 200, 500 9bills.

FUNCTION	SW1	SW2	SW3	SW4	SW5	SW6	SW7	SW8	SW9	SW10
★ 1 Pulse / Hryven 1	OFF	OFF	OFF							
2 Pulse / Hryven 1	OFF	OFF	ON							
3 Pulse / Hryven 1	OFF	ON	OFF							
4 Pulse / Hryven 1	OFF	ON	ON							
5 Pulse / Hryven 1	ON	OFF	OFF							
10 Pulse / Hryven 1	ON	OFF	ON							
20 Pulse / Hryven 1	ON	ON	OFF							
100 Pulse / Hryven 1	ON	ON	ON							
Fast output Pulse Lo= 50ms Hi=100ms				ON						
★ Slow output Pulse Lo= 50ms Hi=300ms				OFF						
Inhibit level Active Low					ON					
★ Inhibit level Active High					OFF					
★ Accept Hryven 1 & 2						ON				
Reject Hryven 1 & 2						OFF				
★ Accept Hryven 5 & 10							ON			
Reject Hryven 5 & 10							OFF			
★ Accept Hryven 20 & 50								ON		
Reject Hryven 20 & 50								OFF		
★ Accept Hryven 100 & 200									ON	
Reject Hryven 100 & 200									OFF	
★ Accept Hryven 500										ON
Reject Hryven 500										OFF

★ Manufacture setting

Note: (1) Please reset the bill acceptor after set the dip switch.

(2) Dip switches 1 to 5 are only used for pulse protocol.

### Currency Assign Data

Interface Bill value	Pulse	ICT	Interface Bill value	Pulse	ICT
BV1	1	1	BV6	50	50
BV2	2	2	BV7	100	100
BV3	5	5	BV8	200	200
BV4	10	10	BV9	500	500
BV5	20	20			

## L77&L77F-UAH9(Pulse/ICT/RS232 A0)

### DIP SWITCHES SETTING : 2(Pulse)

FUNCTION	SW1	SW2	SW3	SW4
★ Pulse Normal High	ON			
Pulse Normal Low	OFF			
★ Pulse Mode		ON	OFF	
ICT Interface		OFF	ON	
RS232 A0 Mode		ON	ON	
Reserved				ON
				OFF

★ Manufacture setting

### DIP SWITCHES SETTING : 2(ICT)

FUNCTION	SW1	SW2	SW3	SW4
★ Reserved	ON			
	OFF			
Pulse Mode		ON	OFF	
★ ICT Interface		OFF	ON	
RS232 A0 Mode		ON	ON	
Reserved				ON
				OFF

★ Manufacture setting

### DIP SWITCHES SETTING : 2(RS232 A0)

FUNCTION	SW1	SW2	SW3	SW4
★ Reserved	ON			
	OFF			
Pulse Mode		ON	OFF	
ICT Interface		OFF	ON	
★ RS232 A0 Mode		ON	ON	
Reserved				ON
				OFF

★ Manufacture setting

Note:

ESCROW DATA		CURRENCY ASSIGN DATA			
Code	Denomination	Code	Country	Denomination	EXP
61h	Hryven 1	61h	5h	01h	00h
62h	Hryven 2	62h	5h	02h	00h
63h	Hryven 5	63h	5h	05h	00h
64h	Hryven 10	64h	5h	0Ah	00h
65h	Hryven 20	65h	5h	14h	00h
66h	Hryven 50	66h	5h	32h	00h
67h	Hryven 100	67h	5h	0Ah	01h
68h	Hryven 200	68h	5h	14h	01h
69h	Hryven 500	69h	5h	32h	01h