



# EUR4

## L77-P3/P6 DIP SWITCHES SETTING : 1(Pulse/ICT)

Supported bill Euro 5, 10, 20, 50 4bills.

	FUNCTION	SW1	SW2	SW3	SW4	SW5	SW6	SW7	SW8	SW9	SW10
★	1 Pulse / Euro 5	OFF	OFF	OFF							
	2 Pulse / Euro 5	OFF	OFF	ON							
	3 Pulse / Euro 5	OFF	ON	OFF							
	4 Pulse / Euro 5	OFF	ON	ON							
	5 Pulse / Euro 5	ON	OFF	OFF							
	10 Pulse / Euro 5	ON	OFF	ON							
	20 Pulse / Euro 5	ON	ON	OFF							
	100 Pulse / Euro 5	ON	ON	ON							
	Fast output Pulse	Lo= 50ms Hi=100ms			ON						
★	Slow output Pulse	Lo= 50ms Hi=300ms			OFF						
	Inhibit level Active Low				ON						
★	Inhibit level Active High				OFF						
★	Accept Euro 5					ON					
	Reject Euro 5					OFF					
★	Accept Euro 10					ON					
	Reject Euro 10					OFF					
★	Accept Euro 20					ON					
	Reject Euro 20					OFF					
★	Accept Euro 50					ON					
	Reject Euro 50					OFF					
	Reserved					ON					
★	Reserved					OFF					

## DIP SWITCHES SETTING : 2

	FUNCTION	SW1	SW2	SW3	SW4
★	Pulse Normal High	ON			
	Pulse Normal Low	OFF			
★	Pulse Mode		ON		
	ICT Protocol Mode		OFF		
★	Reserved			ON	
				OFF	
				ON	
★				OFF	

★ Manufacture setting

Note:(1)Please reset the bill acceptor after set the dip switch.

(2)Dip switches 1 to 5 are only used for pulse protocol.

