

# LX7-A-USD6

## LX7-A Option Switch Settings: 1(Pulse/ICT002U/RS232 A0/NISR)

Supported bill USD 1, 5, 10, 20, 50, 100 6bills.

LX7-A dip-switch settings and functions:

FUNCTION	SW1	SW2	SW3	SW4	SW5	SW6	SW7	SW8	SW1	SW2	SW3	SW4	
★ Reject USD 1	ON												
★ Accept USD 1	OFF												
★ Reject USD 5		ON											
★ Accept USD 5		OFF											
★ Reject USD 10			ON										
★ Accept USD 10			OFF										
★ Reject USD 20				ON									
★ Accept USD 20				OFF									
★ Reject USD 50 & 100					ON								
★ Accept USD 50 & 100					OFF								
Auto Detection SEND Signal	(NISR only)					ON							
★ Normal High SEND Signal	(NISR only)					OFF							
<b>Pulse Mode</b>		<b>Other Mode</b>											
★ Harness Disable	BA stops working when fishing						ON						
★ Harness Enable	Normal						OFF						
★ Inhibit Active High							ON						
★ Inhibit Active Low							OFF						
★ 1 pulse / USD 1								OFF	OFF				
★ 2 pulses / USD 1								ON	OFF				
★ 4 pulses / USD 1								OFF	ON				
★ 20 pulses / USD 1								ON	ON				
★ Pulse Speed	50ms LO / 50ms HI								OFF	OFF			
	60ms LO / 300ms HI								ON	OFF			
	30ms LO / 50ms HI								OFF	ON			
	150ms LO / 150ms HI								ON	ON			

★ Manufacture setting

Note : (1) Default setting.

(2) Use 2nd and 3rd dip of the internal dip-switch to change different interface protocol.

# LX7-A-USD6(Pulse/ICT002U/RS232 A0/NISR)

## DIP SWITCHES SETTING : 2(Pulse)

FUNCTION	SW1	SW2	SW3	SW4
★ Credit-Pulse Normal HIGH	ON			
Credit-Pulse Normal LOW	OFF			
★ Pulse Mode		ON	OFF	
NISR Interface		OFF	ON	
ICT002U Interface		ON	ON	
RS232 A0 Interface		OFF	OFF	
★ Reserved				ON
				OFF

## DIP SWITCHES SETTING : 2(ICT002U)

FUNCTION	SW1	SW2	SW3	SW4
★ Reserved	ON			
	OFF			
Pulse Mode		ON	OFF	
NISR Interface		OFF	ON	
★ ICT002U Interface		ON	ON	
RS232 A0 Interface		OFF	OFF	
★ Reserved				ON
				OFF

## DIP SWITCHES SETTING : 2(RS232 A0)

FUNCTION	SW1	SW2	SW3	SW4
★ Reserved	ON			
	OFF			
Pulse Mode		ON	OFF	
NISR Interface		OFF	ON	
★ RS232 A0 Interface		OFF	OFF	
★ Reserved				ON
				OFF

★ Manufacture setting

## Currency Assign Data

Interface Bill value	Pulse	RS232 A0	NISR	ICT002U
BV1	USD 1	USD 1	USD 1	USD 1
BV2	USD 5			USD 5
BV3	USD 10	USD 5	USD 5	USD 10
BV4	USD 20	USD 10	USD 10	USD 20
BV5	USD 50	USD 20	USD 20	USD 50
BV6	USD 100	USD 50	USD 50	USD 100
BV7		USD 100	USD 100	

## DIP SWITCHES SETTING : 2(NISR)

FUNCTION	SW1	SW2	SW3	SW4
★ Send ERROR CODE	ON			
No ERROR CODE	OFF			
Pulse Mode		ON	OFF	
★ NISR Interface		OFF	ON	
ICT002U Interface		ON	ON	
RS232 A0 Interface		OFF	OFF	
Standard Mode				ON
★ Customized Mode				OFF

## RS232 A0 INFORMATION

BillType Data	
Code	Denomination
1	USD 1
2	Reserved
3	USD 5
4	USD 10
5	USD 20
6	USD 50
7	USD 100