

V7E/LX7-MNT6

V7E/LX7 Option Switch Settings: 1(Pulse/ICT104V/MDB/ICT104U)

Supported bill MNT 100, 500, 1000, 5000, 10000, 20000 6bills.

V7E/LX7 dip-switch settings and functions:

FUNCTION	SW1	SW2	SW3	SW4	SW5	SW6	SW7	SW8	SW1	SW2	SW3	SW4
★ Reject MNT 100	ON											
★ Accept MNT 100	OFF											
★ Reject MNT 500 & 1000		ON										
★ Accept MNT 500 & 1000		OFF										
★ Reject MNT 5000			ON									
★ Accept MNT 5000			OFF									
★ Reject MNT 10000				ON								
★ Accept MNT 10000				OFF								
★ Reject MNT 20000					ON							
★ Accept MNT 20000					OFF							
★ Reserved					ON							
★ Reserved					OFF							
Pulse Mode		Other Mode										
★ Harness Disable	BA stops working when fishing			ON								
★ Harness Enable	Normal			OFF								
★ Inhibit Active High							ON					
★ Inhibit Active Low							OFF					
★ 1 pulse / MNT 100								OFF	OFF			
★ 2 pulses / MNT 100								ON	OFF			
★ 4 pulses / MNT 100								OFF	ON			
★ 20 pulses / MNT 100								ON	ON			
★ Pulse Speed	50ms LO / 50ms HI									OFF	OFF	
	60ms LO / 300ms HI									ON	OFF	
	30ms LO / 50ms HI									OFF	ON	
	150ms LO / 150ms HI									ON	ON	

★ Manufacture setting

Note : (1) Default setting.

(2) Use 2nd and 3rd dip of the internal dip-switch to change different interface protocol.

(3) Remove the front cover and the dip-switch in on the CPU board.

(4) High acceptance mode will increasing accepting rate, however, it will reduce the security level of Bill Acceptor.

V7E/LX7-MNT6(Pulse/ICT104V/MDB/ICT104U)

DIP SWITCHES SETTING : 2(Pulse)

FUNCTION	SW1	SW2	SW3	SW4
★ Credit-Pulse Normal HIGH	ON			
Credit-Pulse Normal LOW	OFF			
★ Pulse Mode		ON	OFF	
★ ICT104U Interface		OFF	ON	
★ ICT104V Interface		ON	ON	
★ MDB Mode		OFF	OFF	
★ Reserved				ON
				OFF

Currency Assign Data

Interface Bill value	Pulse	MDB	ICT104V	ICT104U
BV1	MNT 100	MNT 100	MNT 100	MNT 100
BV2	MNT 500	MNT 500	MNT 500	MNT 500
BV3	MNT 1000	MNT 1000	MNT 1000	MNT 1000
BV4	MNT 5000	MNT 5000	MNT 5000	MNT 5000
BV5	MNT 10000	MNT 10000	MNT 10000	MNT 10000
BV6	MNT 20000	MNT 20000	MNT 20000	MNT 20000

DIP SWITCHES SETTING : 2(ICT104U)

FUNCTION	SW1	SW2	SW3	SW4
★ Reserved	ON			
	OFF			
★ Pulse Mode		ON	OFF	
★ ICT104U Interface		OFF	ON	
★ ICT104V Interface		ON	ON	
★ MDB Mode		OFF	OFF	
★ Reserved				ON
				OFF

DIP SWITCHES SETTING : 2(ICT104V)

FUNCTION	SW1	SW2	SW3	SW4
★ Reserved	ON			
	OFF			
★ Pulse Mode		ON	OFF	
★ ICT104U Interface		OFF	ON	
★ ICT104V Interface		ON	ON	
★ MDB Mode		OFF	OFF	
★ Reserved				ON
				OFF

DIP SWITCHES SETTING : 2(MDB)

FUNCTION	SW1	SW2	SW3	SW4
★ Scaling Factor (SF) = 100 Decimal Point Position (DPP) = 2	ON			
	OFF			
★ Scaling Factor (SF) = 1 Decimal Point Position (DPP) = 0				
★ Pulse Mode		ON	OFF	
★ ICT104U Interface		OFF	ON	
★ ICT104V Interface		ON	ON	
★ MDB Mode		OFF	OFF	
★ Reserved				ON
				OFF

★ Manufacture setting