

# ND-300KM-THB5

## Note Dispenser

**Supported bill THB 20, 50, 100, 500, 1000 5bills.**

ND-300KM dip-switch settings and functions:

SW						
ON	1	2	3	Credit Pulse Timing	Machine Number	Note Dispense Mode
★ 1	ON	ON	ON	500ms±5%	0	Hopper Mode
2	OFF	ON	ON	200ms±5%	1	Hopper Mode
3	ON	OFF	ON	100ms±5%	2	Hopper Mode
4	OFF	OFF	ON	50ms±5%	3	Hopper Mode
5	ON	ON	OFF	500ms±5%	4	Pulse Mode
6	OFF	ON	OFF	200ms±5%	5	Pulse Mode
7	ON	OFF	OFF	100ms±5%	6	Pulse Mode
8	OFF	OFF	OFF	50ms±5%	7	Pulse Mode

DIP SW	4	5	6	7	8	Value	First printing	Dimensions
★ 1	ON	ON	ON	ON	ON	THB 20	Disable	Disable
2	OFF	ON	ON	ON	ON	THB 50	Disable	Disable
3	ON	OFF	ON	ON	ON	THB 100	Disable	Disable
4	OFF	OFF	ON	ON	ON	THB 500	Disable	Disable
5	ON	ON	OFF	ON	ON	THB 1000	Disable	Disable
6	OFF	ON	OFF	ON	ON	Disable	Disable	Disable
7	ON	OFF	OFF	ON	ON	Disable	Disable	Disable
8	OFF	OFF	OFF	ON	ON	Disable	Disable	Disable
9	ON	ON	ON	OFF	ON	Disable	Disable	Disable
10	OFF	ON	ON	OFF	ON	Disable	Disable	Disable
11	ON	OFF	ON	OFF	ON	Disable	Disable	Disable
12	OFF	OFF	ON	OFF	ON	Disable	Disable	Disable
13	ON	ON	OFF	OFF	ON	Disable	Disable	Disable
14	OFF	ON	OFF	OFF	ON	Bypass Mode		
15	ON	OFF	OFF	OFF	ON	Calibration Mode		
16	OFF	OFF	OFF	OFF	ON	Disable		

★ Manufacture Setting.

Note: 1. Setup currency value or Dispense Note mode.