

# P85/P5 DIP SWITCHES SETTING: 1(Parallel)

Supported bill CZK 50(94), 100(95), 200(96), 500(95), 1000(96), 2000(96, 99), 5000(99) 7bills.

## Note: 5000 is not taken by P85 stacker

	FUNCTION	SW1	SW2	SW3	SW4	SW5	SW6	SW7	SW8	SW9	SW10
*	1 Pulse / CZK 50	OFF	OFF	OFF							
	2 Pulse / CZK 50	OFF	OFF	ON							
	3 Pulse / CZK 50	OFF	ON	OFF							
	4 Pulse / CZK 50	OFF	ON	ON							
	5 Pulse / CZK 50	ON	OFF	OFF							
	10 Pulse / CZK 50	ON	OFF	ON							
	20 Pulse / CZK 50	ON	ON	OFF							
	100 Pulse / CZK 50	ON	ON	ON							
	Fast output Pulse Lo= 50ms Hi=100ms				ON						
*	Slow output Pulse Lo= 50ms Hi=300ms				OFF						
	Inhibit level Active Low					ON					
*	Inhibit level Active High					OFF					
*	Accept CZK 50 & 100						ON				
	Reject CZK 50 & 100						OFF				
*	Accept CZK 200 & 500							ON			
	Reject CZK 200 & 500							OFF			
*	Accept CZK 1000								ON		
	Reject CZK 1000								OFF		
*	Accept CZK 2000									ON	
	Reject CZK 2000									OFF	
*	Accept CZK 5000										ON
	Reject CZK 5000										OFF

### ★ Manufacture setting

Note: (1)Please reset the bill acceptor after set the dip switch.

(2)Dip switches 1 to 5 are only used for pulse protocol.

## **DIP SWITCHES SETTING: 2**

_					
ſ	FUNCTION	SW1	SW2	sw3	SW4
- [	Pulse Normal High	ON			
Ī	Pulse Normal Low	OFF			
ſ	Pulse Protocol		ON		
Ī	Parallel Protocol		OFF		
ſ	HOLD			ОИ	
ı	HOLD			OFF	
Ī	Ignore Sensor Problem(Note 1) Acknowledge Sensor Problem (Note 2)				ON
•					

#### ★ Manufacture setting

Note: (1) Sensor 6 problem occurred ==>> BA will be still in working order.

(The face LED will be flashing in short green about 2 seconds everytime you restart BA.)

(2) BA will stop to work when it acknowledges Sensor 6 problem occurred.

(The face LED will be flashing in red.)