

L83-XOF4

L83 DIP SWITCHES SETTING : 1(Pulse/ICT104/MDB)

Supported bill Fr 1000, 2000, 5000, 10000 4bills.

	FUNCTION	SW1	SW2	SW3	SW4	SW5	SW6	SW7	SW8	SW9	SW10
★	1 Pulse / Fr 1000	OFF	OFF	OFF							
	2 Pulse / Fr 1000	OFF	OFF	ON							
	3 Pulse / Fr 1000	OFF	ON	OFF							
	4 Pulse / Fr 1000	OFF	ON	ON							
	5 Pulse / Fr 1000	ON	OFF	OFF							
	10 Pulse / Fr 1000	ON	OFF	ON							
	20 Pulse / Fr 1000	ON	ON	OFF							
	100 Pulse / Fr 1000	ON	ON	ON							
	Fast output Pulse Lo= 50ms Hi=100ms				ON						
★	Slow output Pulse Lo= 50ms Hi=300ms				OFF						
	Inhibit level Active Low					ON					
★	Inhibit level Active High					OFF					
★	Accept Fr 1000						ON				
	Reject Fr 1000						OFF				
★	Accept Fr 2000							ON			
	Reject Fr 2000							OFF			
★	Accept Fr 5000								ON		
	Reject Fr 5000								OFF		
★	Accept Fr 10000									ON	
	Reject Fr 10000									OFF	
★	Reserved										ON
	Reserved										OFF

★ Manufacture setting

Note: (1) Please reset the bill acceptor after set the dip switch.

(2) Dip switches 1 to 5 are only used for pulse protocol.

L83-XOF4(Pulse/ICT104/MDB)

DIP SWITCHES SETTING : 2(Pulse) Currency Assign Data

	FUNCTION	SW1	SW2	SW3	SW4
★	Pulse Normal High	ON			
	Pulse Normal Low	OFF			
★	Pulse Mode		ON	OFF	
	ICT104 Interface		OFF	ON	
	MDB Mode		ON	ON	
	Reserved		OFF	OFF	
★	Reserved				ON
					OFF

★ Manufacture setting

Interface Bill value	Pulse	ICT104	MDB
BV1	Fr 1000	Fr 1000	Fr 1000
BV2	Fr 2000	Fr 2000	Fr 2000
BV3	Fr 5000	Fr 5000	Fr 5000
BV4	Fr 10000	Fr 10000	Fr 10000

DIP SWITCHES SETTING : 2(ICT)

	FUNCTION	SW1	SW2	SW3	SW4
★	Reserved	ON			
		OFF			
	Pulse Mode		ON	OFF	
★	ICT104 Interface		OFF	ON	
	MDB Mode		ON	ON	
	Reserved		OFF	OFF	
★	Reserved				ON
					OFF

★ Manufacture setting

DIP SWITCHES SETTING : 2(MDB)

	FUNCTION	SW1	SW2	SW3	SW4
★	Scaling Factor (SF) = 1 Decimal Point Position (DPP) = 0	ON			
	Scaling Factor (SF) = 10 Decimal Point Position (DPP) = 1	OFF			
	Pulse Mode		ON	OFF	
	ICT104 Interface		OFF	ON	
★	MDB Mode		ON	ON	
	Reserved		OFF	OFF	
★	Reserved				ON
					OFF

★ Manufacture setting