STA II-AED6 Option Switch Settings (Pulse/MDB/ICT104U/Parallel A3) Supported bill AED 5, 10, 20, 50, 100, 200 6bills.

| | FUNCTION | | SW1 | SW2 | SW3 | SW4 | SW5 | SW6 | SW7 | SW8 | SW1 | SW2 | SW3 | SW4 |
|---|--|--------------|------------------------------|-----|---------|--------|-----|-----|-----|-----|-----|-----|-----|-----|
| | Reject AED | 5 & 10 | ON | | | | | | | | | | | |
| * | Accept AED | 5 & 10 | OFF | | | | | | | | | | | |
| | Reject AED | 20 | | ON | | | | | | | | | | |
| * | Accept AED | 20 | | OFF | | | | | | | | | | |
| | Reject AED | 50 | | | ON | | | | | | | | | |
| * | Accept AED | 50 | | | OFF | | | | | | | | | |
| | Reject AED | 100 | | | | ON | | | | | | | | |
| * | Accept AED | 100 | | | | OFF | | | | | | | | |
| | Reject AED | 200 | | | | | ON | | | | | | | |
| * | Accept AED | 200 | | | | | OFF | | | | | | | |
| | Disable Bill Reject 4 BA Stop By 30 S | Sec | | | | | | ON | | | | | | |
| * | Enable Bill Reject 4 BA Stop By 30 S | Times Sec | | | | | | OFF | | | | | | |
| | Stack Banknote when | Power-up | ON | | | | | | | | | | | |
| * | Reject Banknote when | Power-up | | | | | | | OFF | | | | | |
| | Other Interface | | Test Mode (No Communication) | | | | | | | | | | | |
| * | Other interide | | Operation Mode OFF | | | | | | | | | | | |
| | Pulse Mode | | Inhibit Active HIGH (Test) | | | | | | | | | | | |
| * | T disc Wode | | | | Inhibit | Active | LOW | | | OFF | | | | |
| | ENABLE IrDA Dow | vnload | ON | | | | | | | | | | | |
| * | Reserved | | | | | | | | | | OFF | | | |
| | ENABLE INHIBIT-SI | eep Only | | | | | | | | | | ON | | |
| * | 5 second Timeout | Only | | | | | | | | | | OFF | | |
| | NORMAL | | | | | | OFF | OFF | | | | | | |
| | MODE1 | | | | | | OFF | ON | | | | | | |
| | MODE2 | | | | | | | ON | OFF | | | | | |
| * | MODE1+2 | | | | | | | | | | | | ON | ON |

Note: After setting dip switch of the credit pulses, you should reset the bill acceptor again.

NORMAL : No sleep function.

MODE 1 : Bill-acceptor wakes up VMC with banknote only (special cable required).

MODE 2 : VMC wakes up bill-acceptor.

MODE 1+2: Bill-acceptor wakes up with banknote or by VMC.

_Appendix

S7A II-AED6(Pulse/MDB/ICT104U/Parallel A3)

DIP SWITCHES SETTING : 2(Pulse)

| | FUNCTION | SW1 | SW2 | SW3 | SW4 | |
|---|--------------------------|-----|-----|-----|-----|--|
| * | Credit-Pulse Normal High | ON | | | | |
| | Credit-Pulse Normal Low | OFF | | ON | | |
| * | Pulse Mode | | ON | | | |
| | Other Mode | | OFF | | | |
| * | 1 pulse / AED 5 | | | OFF | OFF | |
| | 5 pulses / AED 5 | | | OFF | ON | |
| | 10 pulses / AED 5 | | | ON | OFF | |
| | 25 pulses / AED 5 | | | ON | ON | |

[★] Manufacture setting

DIP SWITCHES SETTING: 2(ICT104U)

| | FUNCTION | SW1 | SW2 | SW3 | SW4 |
|---|-------------|-----|-----|-----|-----|
| * | Reserved | ON | | | |
| | Reserved | OFF | | | |
| | Pulse Mode | | ON | | |
| * | Other Mode | | OFF | | |
| | MDB | | | OFF | OFF |
| * | ICT104U | | | OFF | ON |
| | Reserved | | | ON | ON |
| | Parallel A3 | | | ON | OFF |
| | | | | | |

[★] Manufacture setting

DIP SWITCHES SETTING: 2(MDB)

| | FUNCTION | SW1 | SW2 | SW3 | SW4 |
|---|-------------|-----|-----|-----|-----|
| * | Reserved | ON | | | |
| | Reserved | OFF | | | |
| | Pulse Mode | | ON | | |
| * | Other Mode | | OFF | | |
| * | MDB | | | OFF | OFF |
| | ICT104U | | | OFF | ON |
| | Reserved | | | ON | ON |
| | Parallel A3 | | | ON | OFF |

[★] Manufacture setting

DIP SWITCHES SETTING: 2(Parallel A3)

| | FUNCTION | SW1 | SW2 | SW3 | SW4 |
|---|-------------|-----|-----|-----|-----|
| * | Reserved | ON | | | |
| | Reserved | OFF | | | |
| | Pulse Mode | | ON | | |
| * | Other Mode | | OFF | | |
| | MDB | | | OFF | OFF |
| | ICT104U | | | OFF | ON |
| | Reserved | | | ON | ON |
| * | Parallel A3 | | | ON | OFF |

[★] Manufacture setting

Currency Assign Data

| Interface Bill value | Pulse | MDB | ICT104U | Parallel A3 |
|-------------------------|---------|---------|---------|-------------|
| BV1 | AED 5 | AED 5 | AED 5 | AED 5 |
| BV2 | AED 10 | AED 10 | AED 10 | AED 10 |
| BV3 | AED 20 | AED 20 | AED 20 | AED 20 |
| BV4 | AED 50 | AED 50 | AED 50 | AED 50 |
| BV5 | AED 100 | AED 100 | AED 100 | |
| BV6 | AED 200 | AED 200 | AED 200 | |

© 2015 International Currency Technologies Corporation Vol. 3.0 Part Number : SWQ8AE630-R