

XBA mini-AED6

XBA mini Option Switch Settings: 1(Pulse/MDB/ICT104U/ICT104V)

Supported bill AED 5, 10, 20, 50, 100, 200 6bills.

XBA mini dip-switch settings and functions:

	FUNCTION			SW1	SW2	SW3	SW4	SW5	SW6	SW7	SW8	SW1	SW2	SW3	SW4
★	Reject	AED	5	ON											
	Accept	AED	5	OFF											
★	Reject	AED	10		ON										
	Accept	AED	10		OFF										
★	Reject	AED	20 & 50				ON								
	Accept	AED	20 & 50				OFF								
★	Reject	AED	100 & 200					ON							
	Accept	AED	100 & 200					OFF							
★	Enable Error Downtime							ON							
	Disable Error Downtime							OFF							
★	Disable Bill Reject 4 Times BA Stop By 30 Sec								ON						
	Enable Bill Reject 4 Times BA Stop By 30 Sec								OFF						
★	Stack Banknote when Power-up									ON					
	Reject Banknote when Power-up									OFF					
★	Reserved										ON				
	Reserved										OFF				
★	Inhibit Active High										ON				
	Inhibit Active Low										OFF				
★	Reserved											ON			
	Reserved											OFF			
★	Interface Timing Conversion			50ms LO / 50ms HI									OFF	OFF	
				60ms LO / 300ms HI									ON	OFF	
				30ms LO / 50ms HI									OFF	ON	
				150ms LO / 150ms HI									ON	ON	

★ Manufacture setting

After setting dip switch of the credit pulses,you should reset the bill acceptor again.

Note : (1) Calibration card is needed.

XBA mini-AED6(Pulse/MDB/ICT104V/ICT104U)

Interface Settings: 2(Pulse)

	INTERFACE	SW1	SW2	SW3	SW4
★	Credit-Pulse Normal HIGH	ON			
	Credit-Pulse Normal LOW	OFF			
★	Pulse Mode		ON		
	Other Mode		OFF		
★	1 pulse / AED 5			OFF	OFF
	2 pulses / AED 5			OFF	ON
	4 pulses / AED 5			ON	OFF
	20 pulses / AED 5			ON	ON

★ Manufacture setting

Interface Settings: 2(Other)

	FUNCTION	SW1	SW2	SW3	SW4
★	Reserved	ON			
	Reserved	OFF			
	Pulse Mode		ON		
★	Other Mode		OFF		
	MDB Mode			OFF	OFF
	Reserved			OFF	ON
	ICT104U Mode			ON	OFF
	ICT104V Mode			ON	ON

★ Manufacture setting

Currency Assign Data

Interface Bill value	ICT104U	ICT104V	Pulse	MDB
BV1	AED 5	AED 5	AED 5	AED 5
BV2	AED 10	AED 10	AED 10	AED 10
BV3	AED 20	AED 20	AED 20	AED 20
BV4	AED 50	AED 50	AED 50	AED 50
BV5	AED 100	AED 100	AED 100	AED 100
BV6	AED 200	AED 200	AED 200	AED 200

Interface Settings: 2(MDB)

	FUNCTION	SW1	SW2	SW3	SW4
★	Scaling Factor (SF) = 100 Decimal Point Position (DPP) = 2	ON			
	Scaling Factor (SF) = 1 Decimal Point Position (DPP) = 0	OFF			
	Pulse Mode		ON		
★	Other Mode		OFF		
★	MDB Mode			OFF	OFF
	Reserved			OFF	ON
	ICT104U Mode			ON	OFF
	ICT104V Mode			ON	ON

★ Manufacture setting

Interface Settings: 2(ICT104V)

	FUNCTION	SW1	SW2	SW3	SW4
★	Connect with coin changer	ON			
	Connect with ICT JPSTD Converter board	OFF			
	Pulse Mode		ON		
★	Other Mode		OFF		
	MDB Mode			OFF	OFF
	Reserved			OFF	ON
	ICT104U Mode			ON	OFF
★	ICT104V Mode			ON	ON

★ Manufacture setting