

NBA-KES5

NBA DIP SWITCH SETTINGS: 1 (Pulse/RS232 A0/ICT104U/ICT104V/ccTalk)

Supported bill KES 50, 100, 200, 500, 1000 5 bills.

	FUNCTION	SW1	SW2	SW3	SW4	SW5	SW6	SW7	SW8
⊙	Accept KES 50	ON							
	Reject KES 50	OFF							
⊙	Accept KES 100		ON						
	Reject KES 100		OFF						
⊙	Accept KES 200			ON					
	Reject KES 200			OFF					
⊙	Accept KES 500				ON				
	Reject KES 500				OFF				
⊙	Accept KES 1000					ON			
	Reject KES 1000					OFF			
	Turn Off Bezel LED						ON		
⊙	Turn On Bezel LED						OFF		
▲ ⊙	Harness Enable							ON	
▲	Harness Disable							OFF	
▲ ⊙	Inhibit Active High	CRC 16-bit checksum(ccTalk only)							ON
▲	Inhibit Active Low	8-bit checksum (ccTalk only)							OFF

DIP SWITCHES SETTING : 2

	FUNCTION	SW1	SW2	SW3	SW4	SW1	SW2	SW3	SW4
▲ ⊙	1 pulse / KES 50	OFF	OFF						
▲	2 pulses / KES 50	ON	OFF						
▲	5 pulses / KES 50	OFF	ON						
▲	10 pulses / KES 50	ON	ON						
▲ ⊙	Pulse Speed	50ms LO / 50ms HI		OFF	OFF				
▲		30ms LO / 50ms HI		ON	OFF				
▲		60ms LO / 300ms HI		OFF	ON				
▲		150ms LO / 150ms HI		ON	ON				
⊙	ccTalk Mode					OFF	OFF		
	ICT104V Mode					ON	OFF		
	ICT104U Mode					OFF	ON		
	RS232 A0 Mode					ON	ON		
	ccTalk Parameters Restore Switch Please see "Note.3" for detail							ON	
⊙	ccTalk Interface							OFF	
⊙	Encryption Mode(for ccTalk Mode use only)								ON
	Decrypt Mode								OFF

(⊙) Factory setting. (▲) For pulse interface only.

Note: (3) Turn this dip to with restart the bill acceptor will restore CCTalk address to its default value of 40 and the encryption key to its default value of 123456.

NBA-KES5(Pulse/RS232 A0/ICT104U/ICT104V/ccTalk)

DIP SWITCHES SETTING : 3

	FUNCTION	SW1	SW2	SW3	SW4
▲ ⊙	Credit-Pulse Normal HIGH	ON			
▲	Credit-Pulse Normal LOW	OFF			
▲ ⊙	Pulse Mode		ON		
	Others Mode (Note.2)		OFF		
	RFID function Enable			ON	
⊙	RFID function Disable			OFF	
	Laser error occurred BA will be still in working order				ON
⊙	BA will stop to work when it acknowledges Laser error occurred				OFF

(⊙) Factory setting.

(▲) For pulse interface only.

Note: (1) Please reset the bill acceptor after any changes on Dip switch.

(2) SW2 (front panel right block) Dip Switch 1 to 4 are only for Pulse mode. if set to others mode, SW2 Dip Switch 1 to 4 can change to different interface.

(3) Turn this dip to with restart the bill acceptor will restore CCTalk address to its default value of 40 and the encryption key to its default value of 123456.

(4) Barcode reader calibration procedure :

1. Turn all bill values under reject mode.
2. Restart power.

3. Insert the blank barcode ticket to calibrate the reader head, and NBA's bezel flashing in green for 2 seconds.

4. Restore the original dip switch setting and restart the power.

(5) RS232 A0 Information:

BillType Data	
Code	Denomination
1	Reserved
2	Reserved
3	KES 50
4	KES 100
5	KES 200
6	KES 500
7	KES 1000
8	Reserved

Currency Assign Data

Interface Bill value	Pulse	RS232 A0	ICT104U	ICT104V	ccTalk
BV1	KES 50	KES 50	KES 50	KES 50	KES 50
BV2	KES 100	KES 100	KES 100	KES 100	KES 100
BV3	KES 200	KES 200	KES 200	KES 200	KES 200
BV4	KES 500	KES 500	KES 500	KES 500	KES 500
BV5	KES 1000	KES 1000	KES 1000	KES 1000	KES 1000