

NBA-KZT7

NBA DIP SWITCH SETTINGS: 1 (Pulse/RS232 A0/ICT104U/RS232 A1/ccTalk)

Supported bill KZT 200, 500, 1000, 2000, 5000, 10000, 20000 7bills.

	FUNCTION	SW1	SW2	SW3	SW4	SW5	SW6	SW7	SW8
⊙	Accept KZT 200 & 500	ON							
	Reject KZT 200 & 500	OFF							
⊙	Accept KZT 1000		ON						
	Reject KZT 1000		OFF						
⊙	Accept KZT 2000			ON					
	Reject KZT 2000			OFF					
⊙	Accept KZT 5000				ON				
	Reject KZT 5000				OFF				
⊙	Accept KZT 10000					ON			
	Reject KZT 10000					OFF			
⊙	Accept KZT 20000						ON		
	Reject KZT 20000						OFF		
▲ ⊙	Harness Enable							ON	
▲	Harness Disable							OFF	
▲ ⊙	Inhibit Active High	CRC 16-bit chencksum (ccTalk only)							ON
▲	Inhibit Active Low	8-bit chencksum (ccTalk only)							OFF

DIP SWITCHES SETTING : 2

	FUNCTION	SW1	SW2	SW3	SW4	SW1	SW2	SW3	SW4
▲ ⊙	1 pulse / KZT 100	OFF	OFF						
▲	2 pulses / KZT 100	ON	OFF						
▲	4 pulses / KZT 100	OFF	ON						
▲	10 pulses / KZT 100	ON	ON						
▲ ⊙	Pulse Speed	50ms LO / 50ms HI		OFF	OFF				
▲		30ms LO / 50ms HI		ON	OFF				
▲		60ms LO / 300ms HI		OFF	ON				
▲		150ms LO / 150ms HI		ON	ON				
⊙	ccTalk Mode					OFF	OFF		
	ICT104U Mode					ON	OFF		
	RS232 A1 Mode					OFF	ON		
	RS232 A0 Mode					ON	ON		
	CCTalk Parameters Restore switch (Please see Note.3 for Detail)							ON	
⊙	ccTalk Interface							OFF	
⊙	Encryption Mode(for ccTalk Mode use only)								ON
	Decrypt Mode								OFF

(⊙) Factory setting. (▲) For pulse interface only.

Note: (3) Turn this dip to with restart the bill acceptor will restore CCTalk address to its default value of 40 and the encryption key to its default value of 123456.

NBA-KZT7(Pulse/RS232 A0/ICT104U/RS232 A1/ccTalk)

DIP SWITCHES SETTING : 3

	FUNCTION	SW1	SW2	SW3	SW4
▲ ⊙	Credit-Pulse Normal HIGH	ON			
▲	Credit-Pulse Normal LOW	OFF			
▲ ⊙	Pulse Mode		ON		
	Others Mode (Note.2)		OFF		
	RFID function Enable			ON	
⊙	RFID function Disable			OFF	
	Laser error occurred BA will be still in working order				ON
⊙	BA will stop to work when it acknowledges Laser error occurred				OFF

(⊙) Factory setting.

(▲) For pulse interface only.

Note: (1) Please reset the bill acceptor after any changes on Dip switch.

(2) SW2 (front panel right block) Dip Switch 1 to 4 are only for Pulse mode. if set to others mode, SW2 Dip Switch 1 to 4 can change to different interface.

(3) Turn this dip to with restart the bill acceptor will restore CCTalk address to its default value of 40 and the encryption key to its default value of 123456.

(4) Barcode reader calibration procedure :

1. Turn all bill values under reject mode.
2. Restart power.
3. Insert the blank barcode ticket to calibrate the reader head, and NBA's bezel flashing in green for 2 seconds.
4. Restore the original dip switch setting and restart the power.

(5) RS232 A0 Information:

BillType Data	
Code	Denomination
1	Reserved
2	200
3	500
4	1000
5	2000
6	5000
7	10000
8	20000

Currency Assign Data

Interface	Pulse	RS232 A0	ICT104U	RS232 A1	ccTalk
BV1	KZT 200	KZT 200	KZT 200	KZT 200	KZT 200
BV2	KZT 500	KZT 500	KZT 500	KZT 500	KZT 500
BV3	KZT 1000	KZT 1000	KZT 1000	KZT 1000	KZT 1000
BV4	KZT 2000	KZT 2000	KZT 2000	KZT 2000	KZT 2000
BV5	KZT 5000	KZT 5000	KZT 5000	KZT 5000	KZT 5000
BV6	KZT 10000	KZT 10000	KZT 10000	KZT 10000	KZT 10000
BV7	KZT 20000	KZT 20000	KZT 20000	KZT 20000	KZT 20000