

NBA-PLN11(PLN5+EUR6)

NBA DIP SWITCH SETTINGS: 1 (Pulse/RS232 A0/ICT104U/RS232 A1/ccTalk)

Supported bill PLN 10, 20, 50, 100, 200

5 bills.

EUR 5, 10, 20, 50, 100, 200

6 bills.

	FUNCTION	SW1	SW2	SW3	SW4	SW5	SW6	SW7	SW8
⊙	Accept PLN 10 & 20	ON							
	Reject PLN 10 & 20	OFF							
⊙	Accept PLN 50 & 100		ON						
	Reject PLN 50 & 100		OFF						
⊙	Accept PLN 200			ON					
	Reject PLN 200			OFF					
⊙	Accept EUR 5 & 10 & 20				ON				
	Reject EUR 5 & 10 & 20				OFF				
⊙	Accept EUR 50 & 100					ON			
	Reject EUR 50 & 100					OFF			
⊙	Accept EUR 200						ON		
	Reject EUR 200						OFF		
▲ ⊙	Harness Enable							ON	
▲	Harness Disable							OFF	
▲ ⊙	Inhibit Active High	CRC 16-bit checksum(ccTalk only)							ON
▲	Inhibit Active Low	8-bit checksum (ccTalk only)							OFF

DIP SWITCHES SETTING : 2

	FUNCTION	SW1	SW2	SW3	SW4	SW1	SW2	SW3	SW4
▲ ⊙	1 pulse / PLN 10 & EUR 5	OFF	OFF						
▲	2 pulses / PLN 10 & EUR 5	ON	OFF						
▲	5 pulses / PLN 10 & EUR 5	OFF	ON						
▲	10 pulses / PLN 10 & EUR 5	ON	ON						
▲ ⊙	Pulse Speed	50ms LO / 50ms HI		OFF	OFF				
▲		30ms LO / 50ms HI		ON	OFF				
▲		60ms LO / 300ms HI		OFF	ON				
▲		150ms LO / 150ms HI		ON	ON				
⊙	ccTalk Mode					OFF	OFF		
	ICT104U Mode					ON	OFF		
	RS232 A1 Mode					OFF	ON		
	RS232 A0 Mode					ON	ON		
	ccTalk Parameters Restore Switch Please see "Note.3" for detail							ON	
⊙	ccTalk Interface							OFF	
⊙	Encryption Mode(for ccTalk Mode use only)								ON
	Decrypt Mode								OFF

(⊙) Factory setting. (▲) For pulse interface only.

NBA-PLN11(PLN5+EUR6)(Pulse/RS232 A0/ICT104U/RS232 A1/ccTalk)

DIP SWITCHES SETTING : 3

	FUNCTION	SW1	SW2	SW3	SW4
▲ ⊙	Credit-Pulse Normal HIGH	ON			
▲	Credit-Pulse Normal LOW	OFF			
▲ ⊙	Pulse Mode		ON		
	Others Mode (Note.2)		OFF		
	RFID function Enable			ON	
⊙	RFID function Disable			OFF	
	Laser error occurred BA will be still in working order				ON
⊙	BA will stop to work when it acknowledges Laser error occurred				OFF

(⊙) Factory setting.

(▲) For pulse interface only.

Note: (1) Please reset the bill acceptor after any changes on Dip switch.

(2) SW2 (front panel right block) Dip Switch 1 to 4 are only for Pulse mode. if set to others mode, SW2 Dip Switch 1 to 4 can change to different interface.

(3) Turn this dip to with restart the bill acceptor will restore ccTalk address to its default value of 40 and the encryption key to its default value of 123456.

(4) Barcode reader calibration procedure :

1. Turn all bill values under reject mode.
2. Restart power.
3. Insert the blank barcode ticket to calibrate the reader head, and NBA's bezel flashing in green for 2 seconds.
4. Restore the original dip switch setting and restart the power.

(5) RS232 A0 Information:

BillType Data	
Code	Denomination
1	PLN 10
2	PLN 20
3	PLN 50
4	PLN 100
5	PLN 200
6	EUR 5
7	EUR 10
8	EUR 20
9	EUR 50
10	EUR 100
11	EUR 200

Currency Assign Data

Interface Bill value	Pulse	RS232 A0	ICT104U	RS232 A1	ccTalk
BV1	PLN 10	PLN 10	PLN 10	PLN 10	PLN 10
BV2	PLN 20	PLN 20	PLN 20	PLN 20	PLN 20
BV3	PLN 50	PLN 50	PLN 50	PLN 50	PLN 50
BV4	PLN 100	PLN 100	PLN 100	PLN 100	PLN 100
BV5	PLN 200	PLN 200	PLN 200	PLN 200	PLN 200
BV6	EUR 5	EUR 5	EUR 5	EUR 5	EUR 5
BV7	EUR 10	EUR 10	EUR 10	EUR 10	EUR 10
BV8	EUR 20	EUR 20	EUR 20	EUR 20	EUR 20
BV9	EUR 50	EUR 50	EUR 50	EUR 50	EUR 50
BV10	EUR 100	EUR 100	EUR 100	EUR 100	EUR 100
BV11	EUR 200	EUR 200	EUR 200	EUR 200	EUR 200

© 2016 International Currency Technologies Corporation
V. 3.0 Part Number : SWM0PLC30-R