

## XBA mini-BHD2

### XBA mini Option Switch Settings: 1(Pulse/MDB/JPSTD/ICT104U/ICT104V)

## Supported bill BHD 0.5, 1 2bills.

XBA mini dip-switch settings and functions:

	FUNCTION	SW1	SW2	SW3	SW4	SW5	SW6	SW7	SW8	SW1	SW2	SW3	SW4
★	Reject BHD 0.5	ON											
	Accept BHD 0.5	OFF											
★	Reject BHD 1		ON										
★	Accept BHD 1		OFF										
	Reserved			ON									
★	Reserved			OFF									
	Reserved				ON								
★	Reserved				OFF								
	Reserved					ON							
★	Reserved					OFF							
	Disable Bill Reject 4 Times BA Stop By 30 Sec					ON							
★	Enable Bill Reject 4 Times BA Stop By 30 Sec					OFF							
	Stack Banknote when Power-up						ON						
★	Reject Banknote when Power-up						OFF						
	Reserved							ON					
★	Reserved							OFF					
	Inhibit Active High								ON				
★	Inhibit Active Low								OFF				
	Reserved									ON			
★	Reserved									OFF			
★	Interface Timing Conversion	50ms LO / 50ms HI								OFF	OFF		
		60ms LO / 300ms HI								ON	OFF		
		30ms LO / 50ms HI								OFF	ON		
		150ms LO / 150ms HI								ON	ON		

★ Manufacture setting

After setting dip switch of the credit pulses, you should reset the bill acceptor again.

Note : 1. Calibration card is needed.

## XBA mini-BHD2(Pulse/MDB/JPSTD/ICT104U/ICT104V)

### Interface Settings: 2(Pulse)

	INTERFACE	SW1	SW2	SW3	SW4
★	Credit-Pulse Normal HIGH	ON			
	Credit-Pulse Normal LOW	OFF			
★	Pulse Mode		ON		
	Other Mode		OFF		
★	1 pulse / BHD 0.5			OFF	OFF
	2 pulses / BHD 0.5			OFF	ON
	4 pulses / BHD 0.5			ON	OFF
	20 pulses / BHD 0.5			ON	ON

★ Manufacture setting

### Interface Settings: 2(MDB)

	FUNCTION	SW1	SW2	SW3	SW4
★	Scaling Factor (SF) = 100 Decimal Point Position (DPP) = 3	ON			
	Scaling Factor (SF) = 1 Decimal Point Position (DPP) = 1	OFF			
	Pulse Mode		ON		
★	Other Mode		OFF		
★	MDB Mode			OFF	OFF
	JPSTD Mode			OFF	ON
	ICT104U Mode			ON	OFF
	ICT104V Mode			ON	ON

★ Manufacture setting

### Interface Settings: 2(Other)

	FUNCTION	SW1	SW2	SW3	SW4
★	Reserved	ON			
	Reserved	OFF			
	Pulse Mode		ON		
★	Other Mode		OFF		
	MDB Mode			OFF	OFF
	JPSTD Mode			OFF	ON
	ICT104U Mode			ON	OFF
	ICT104V Mode			ON	ON

★ Manufacture setting

### Interface Settings: 2(ICT104V)

	FUNCTION	SW1	SW2	SW3	SW4
★	Connect with coin changer	ON			
	Connect with ICT JPSTD Converter board	OFF			
	Pulse Mode		ON		
★	Other Mode		OFF		
	MDB Mode			OFF	OFF
	JPSTD Mode			OFF	ON
	ICT104U Mode			ON	OFF
★	ICT104V Mode			ON	ON

★ Manufacture setting

## Currency Assign Data

Interface Bill value	Pulse	MDB	ICT104U	ICT104V	JPSTD
BV1	BHD 0.5	BHD 0.5	BHD 0.5	BHD 0.5	BHD 0.5
BV2	BHD 1	BHD 1	BHD 1	BHD 1	