V7-TRY5

V7 Option Switch Settings: 1 (Pulse/MDB/ICT004U)

Supported bill TRY 5, 10, 20, 50, 100

5bills.

V7 dip-switch settings and functions:

					1				
	FUNCTION	SW1	SW2	SW3	SW4	SW5	SW6	SW7	SW8
	Reject TRY 5	ON							
*	Accept TRY 5	OFF							
	Reject TRY 10		ON						
*	Accept TRY 10		OFF						
	Reject TRY 20			ON					
*	Accept TRY 20			OFF					
	Reject TRY 50				ON				
*	Accept TRY 50				OFF				
	Reject TRY 100					ON			
*	Accept TRY 100					OFF			
	Reserved						ON		
*	Reserved						OFF		
	Harness Disable							ON	
*	Harness Enable							OFF	
	Inhiblit Active High								ON
*	Inhibit Active Low								OFF

Factory configuration has all switches in the OFF position.

V7 Interface Settings: 2 (Pulse)

	INTERFACE	SW1	SW2	SW3	SW4
*	1 pulse / TRY 5	OFF	OFF		
	5 pulse / TRY 5	ON	OFF		
	10 pulse / TRY 5	OFF	ON		
	20 pulse / TRY 5	ON	ON		
*	50ms on / 50ms off			OFF	OFF
	60ms on / 300ms off			ON	OFF
	30ms on / 50ms off			OFF	ON
	150ms on / 150ms off			ON	ON

[★] Manufacture setting

V7-TRY5(Pulse/MDB/ICT004U)

V7 Interface Settings: 3 (ICT) V7 Interface Settings: 3 (Pulse)

	INTERFACE	SW1	SW2	SW3	SW4
	Reserved	ON			
*	Reserved	OFF			
	Pulse Mode		ON	OFF	
	MDB Interface		OFF	OFF	
*	ICT Interface		OFF	ON	
	Reserved		ON	ON	
	Reserved				ON
*	Neserveu				OFF

	INTERFACE	SW1	SW2	SW3	SW4
*	Credit-Pulse Normal High	ON			
	Credit-Pulse Normal Low	OFF			
*	Pulse Mode		ON	OFF	
	MDB Interface		OFF	OFF	
	ICT Interface		OFF	ON	
	Reserved		ON	ON	
	Reserved				ON
*	Neserved				

V7 Interface Settings: 3 (MDB)

	INTERFACE	SW1	SW2	SW3	SW4
*	Scaling Factor (SF) = 100 Decimal Point Position (DPP) = 2	ON			
	Scaling Factor (SF) = 1 Decimal Point Position (DPP) = 0	OFF			
	Pulse Mode		ON	OFF	
*	MDB Interface		OFF	OFF	
	ICT Interface		OFF	ON	
	Reserved		ON	ON	
	Reserved				ON
*	176961760				OFF

Currency Assign Data

Interface Bill value	ICT	Pulse	MDB	
BV1	TRY 5	TRY 5	TRY 5	
BV2	TRY 10	TRY 10	TRY 10	
BV3	TRY 20	TRY 20	TRY 20	
BV4	TRY 50	TRY 50	TRY 50	
BV5	TRY 100	TRY 100	TRY 100	

Note: 1.Use 2nd and 3rd dip of the internal dip-switch to change different interface protocol.

2.Remove the front cover and the dip-switch in on the CPU board.

(Please refer to "Sw1" setting.)