

BRV-COP7

BRV Option Switch Settings: 1(ICT-BC/MDB/JPSTD Dummy/MDB Dummy)

Supported bill COP 1000, 2000, 5000, 10000, 20000, 50000, 100000 7bills.

BRV dip-switch settings and functions:

FUNCTION	SW1	SW2	SW3	SW4	SW5	SW6	SW7	SW8	SW1	SW2	SW3	SW4
Reject Col\$ 1000	ON											
★ Accept Col\$ 1000	OFF											
Reject Col\$ 2000 & 5000		ON										
★ Accept Col\$ 2000 & 5000		OFF										
Reject Col\$ 10000			ON									
★ Accept Col\$ 10000			OFF									
Reject Col\$ 20000				ON								
★ Accept Col\$ 20000				OFF								
Reject Col\$ 50000 & 100000					ON							
★ Accept Col\$ 50000 & 100000					OFF							
★ Normal						OFF	OFF					
Load Banknote to Recycle						ON	OFF					
Load Banknote to Stacker						OFF	ON					
Unload Banknote to Stacker						ON	ON					
Reserved								ON				
★ Reserved								OFF				
MDB Mode	SW1	SW2	SW3	SW4	JPSTD Dummy Mode							
Reserved	ON				★ 255 Bank Note Limitation Per Transaction	ON	ON	ON				
★ Reserved	OFF				1 Bank Note Limitation Per Transaction	OFF	OFF	OFF				
Reserved		ON			2 Bank Note Limitation Per Transaction	ON	OFF	OFF				
★ Reserved		OFF			3 Bank Note Limitation Per Transaction	OFF	ON	OFF				
Reserved			ON		4 Bank Note Limitation Per Transaction	ON	ON	OFF				
★ Reserved				ON	5 Bank Note Limitation Per Transaction	OFF	OFF	ON				
Reserved				OFF	6 Bank Note Limitation Per Transaction	ON	OFF	ON				
★ Reserved					7 Bank Note Limitation Per Transaction	OFF	ON	ON				
Virtual MDB Recycler Function (Note.4)				ON	No Refund After the Deal							ON
★ Standard MDB Recycler Function				OFF	★ Refund After the Deal							OFF

★ Manufacture setting

Note : (1) After setting dip switch of the credit pulses,you should reset the bill acceptor again.

(2) Please reset the bill acceptor after set the dip switch.

(3) Calibration card is needed.

(4) Recycled Banknote represents virtual MDB coin type.

(5) JPSTD Dummy Mode credit divide by1000

(6) Virtual Coin Changer : Scaling Factor = 1, Decimal Point Position= 0.

(7) The function(credit divide by1000) is used at standard MDB recycler mode.

(8) The function(credit divide by100) is used at standard MDB recycler mode.

Appendix

BRV-COP7(ICT-BC/MDB/JPSTD Dummy/MDB Dummy)

Interface Settings: 2(ICT-BC)

INTERFACE	SW5	SW6	SW7	SW8
Reserved	ON			
★ Reserved	OFF			
Connect with MDB Connector		ON		
★ Connect with RS232 Connector		OFF		
MDB Mode			OFF	OFF
JPSTD Dummy Mode			OFF	ON
MDB Dummy Mode			ON	OFF
★ ICT-BC Mode			ON	ON

★ Manufacture setting

Interface Settings: 2(JPSTD Dummy)

INTERFACE	SW5	SW6	SW7	SW8
Escrow (JPSTD Dummy Mode)	ON			
★ No Escrow (JPSTD Dummy Mode)	OFF			
Reserved		ON		
★ Reserved		OFF		
MDB Mode			OFF	OFF
★ JPSTD Dummy Mode (Note.5)			OFF	ON
MDB Dummy Mode			ON	OFF
ICT-BC Mode			ON	ON

★ Manufacture setting

Interface Settings: 2(MDB)

INTERFACE	SW5	SW6	SW7	SW8
★ Normal Credit (Note.6)	OFF	OFF		
Credit divide by 1000 (Note.7)	OFF	ON		
Credit divide by 100 (Note.8)	ON	OFF		
Reserved	ON	ON		
★ MDB Mode			OFF	OFF
JPSTD Dummy Mode			OFF	ON
MDB Dummy Mode			ON	OFF
ICT-BC Mode			ON	ON

★ Manufacture setting

Interface Settings: 2(MDB Dummy)

INTERFACE	SW5	SW6	SW7	SW8
★ Normal Credit (Note.6)	OFF	OFF		
Credit divide by 1000 (Note.7)	OFF	ON		
Credit divide by 100 (Note.8)	ON	OFF		
Reserved	ON	ON		
MDB Mode			OFF	OFF
JPSTD Dummy Mode			OFF	ON
★ MDB Dummy Mode			ON	OFF
ICT-BC Mode			ON	ON

★ Manufacture setting

Currency Assign Data

Interface Bill value	JPSTD Dummy	ICT-BC	MDB	MDB Dummy	Recycler banknote inventory	
BV1	Col\$ 1000	Col\$ 1000	Col\$ 1000	Col\$ 1000	Col\$ 1000	35 pcs
BV2	Col\$ 2000	Col\$ 2000	Col\$ 2000	Col\$ 2000	Col\$ 2000	35 pcs
BV3	Col\$ 5000	Col\$ 5000	Col\$ 5000	Col\$ 5000	Col\$ 5000	35 pcs
BV4	Col\$ 10000	Col\$ 10000	Col\$ 10000	Col\$ 10000	Col\$ 10000	35 pcs
BV5	Col\$ 20000	Col\$ 20000	Col\$ 20000	Col\$ 20000	Col\$ 20000	35 pcs
BV6	Col\$ 50000	Col\$ 50000	Col\$ 50000	Col\$ 50000	Col\$ 50000	30 pcs
BV7	Col\$ 100000	Col\$ 100000	Col\$ 100000	Col\$ 100000	Col\$ 100000	30 pcs