

V7P-UAH6

V7P Option Switch Settings: 1(Pulse/ICT104V/ICT104U/MDB)

Supported bill UAH 1, 2, 5, 10, 20, 50 6bills.

V7P dip-switch settings and functions:

| FUNCTION | SW1 | SW2 | SW3 | SW4 | SW5 | SW6 | SW7 | SW8 | SW1 | SW2 | SW3 | SW4 |
|-------------------------------|---------------------|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|
| ★ Reject UAH 1 & 2 | ON | | | | | | | | | | | |
| ★ Accept UAH 1 & 2 | OFF | | | | | | | | | | | |
| ★ Reject UAH 5 | | ON | | | | | | | | | | |
| ★ Accept UAH 5 | | OFF | | | | | | | | | | |
| ★ Reject UAH 10 | | | ON | | | | | | | | | |
| ★ Accept UAH 10 | | | OFF | | | | | | | | | |
| ★ Reject UAH 20 | | | | ON | | | | | | | | |
| ★ Accept UAH 20 | | | | OFF | | | | | | | | |
| ★ Reject UAH 50 | | | | | ON | | | | | | | |
| ★ Accept UAH 50 | | | | | OFF | | | | | | | |
| ★ Reserved | | | | | | ON | | | | | | |
| ★ Reserved | | | | | | OFF | | | | | | |
| ★ Harness Disable | | | | | | | ON | | | | | |
| ★ Harness Enable | | | | | | | OFF | | | | | |
| ★ Inhibit Active High | | | | | | | | ON | | | | |
| ★ Inhibit Active Low | | | | | | | | OFF | | | | |
| ★ 1 pulse / UAH 1 | | | | | | | | | OFF | OFF | | |
| ★ 5 pulses / UAH 1 | | | | | | | | | ON | OFF | | |
| ★ 10 pulses / UAH 1 | | | | | | | | | OFF | ON | | |
| ★ 20 pulses / UAH 1 | | | | | | | | | ON | ON | | |
| ★ Interface Timing Conversion | 50ms LO / 50ms HI | | | | | | | | OFF | OFF | | |
| | 60ms LO / 300ms HI | | | | | | | | ON | OFF | | |
| | 30ms LO / 50ms HI | | | | | | | | OFF | ON | | |
| | 150ms LO / 150ms HI | | | | | | | | ON | ON | | |

★ Manufacture setting

◆ Note : (1) Default setting.

(2) Use 2nd and 3rd dip of the internal dip-switch to change different interface protocol.

(3) Remove the front cover and the dip-switch in on the CPU board.

V7P-UAH6(Pulse/ICT104V/ICT104U/MDB)

Interface Settings: 2(Pulse)

| INTERFACE | SW1 | SW2 | SW3 | SW4 |
|----------------------------|-----|-----|-----|-----|
| ★ Credit-Pulse Normal HIGH | ON | | | |
| Credit-Pulse Normal LOW | OFF | | | |
| ★ Pulse Mode | | ON | OFF | |
| ICT104U Mode | | OFF | OFF | |
| ICT104V Mode | | OFF | ON | |
| MDB Mode | | ON | ON | |
| ★ Reserved | | | | ON |
| | | | | OFF |

★ Manufacture setting

Currency Assign Data

| Interface Bill value | ICT104U | ICT104V | MDB | Pulse |
|----------------------|---------|---------|--------|--------|
| BV1 | UAH 1 | UAH 1 | UAH 1 | UAH 1 |
| BV2 | UAH 2 | UAH 2 | UAH 2 | UAH 2 |
| BV3 | UAH 5 | UAH 5 | UAH 5 | UAH 5 |
| BV4 | UAH 10 | UAH 10 | UAH 10 | UAH 10 |
| BV5 | UAH 20 | UAH 20 | UAH 20 | UAH 20 |
| BV6 | UAH 50 | UAH 50 | UAH 50 | UAH 50 |

Interface Settings: 2(ICT104U/ICT104V)

| INTERFACE | SW1 | SW2 | SW3 | SW4 |
|----------------|-----|-----|-----|-----|
| ★ Reserved | ON | | | |
| Reserved | OFF | | | |
| Pulse Mode | | ON | OFF | |
| ★ ICT104U Mode | | OFF | OFF | |
| ICT104V Mode | | OFF | ON | |
| MDB Mode | | ON | ON | |
| ★ Reserved | | | | ON |
| | | | | OFF |

★ Manufacture setting

| INTERFACE | SW1 | SW2 | SW3 | SW4 |
|----------------|-----|-----|-----|-----|
| ★ Reserved | ON | | | |
| Reserved | OFF | | | |
| Pulse Mode | | ON | OFF | |
| ★ ICT104U Mode | | OFF | OFF | |
| ICT104V Mode | | OFF | ON | |
| MDB Mode | | ON | ON | |
| ★ Reserved | | | | ON |
| | | | | OFF |

★ Manufacture setting

Interface Settings: 2(MDB)

| FUNCTION | SW1 | SW2 | SW3 | SW4 |
|---|-----|-----|-----|-----|
| ★ Scaling Factor (SF) = 100 Decimal Point Position (DPP) = 2 | ON | | | |
| Scaling Factor (SF) = 1 Decimal Point Position (DPP) = 0 | OFF | | | |
| Pulse Mode | | ON | OFF | |
| ICT104U Mode | | OFF | OFF | |
| ICT104V Mode | | OFF | ON | |
| ★ MDB Mode | | ON | ON | |
| ★ Reserved | | | | ON |
| | | | | OFF |

★ Manufacture setting