

## XBA mini-GNF5

### XBA mini Option Switch Settings: 1(Pulse/MDB/JPSTD/ICT104U/ICT104V)

Supported bill GNF 1000, 2000, 5000, 10000, 20000 5bills.

XBA mini dip-switch settings and functions:

FUNCTION	SW1	SW2	SW3	SW4	SW5	SW6	SW7	SW8	SW1	SW2	SW3	SW4
★ Reject GNF 1000	ON											
★ Accept GNF 1000	OFF											
★ Reject GNF 2000		ON										
★ Accept GNF 2000		OFF										
★ Reject GNF 5000			ON									
★ Accept GNF 5000			OFF									
★ Reject GNF 10000				ON								
★ Accept GNF 10000				OFF								
★ Reject GNF 20000					ON							
★ Accept GNF 20000					OFF							
★ Disable Bill Reject 4 Times BA Stop By 30 Sec						ON						
★ Enable Bill Reject 4 Times BA Stop By 30 Sec						OFF						
★ Stack Banknote when Power-up							ON					
★ Reject Banknote when Power-up							OFF					
★ Reserved								ON				
★ Reserved								OFF				
★ Inhibit Active High									ON			
★ Inhibit Active Low									OFF			
★ Reserved										ON		
★ Reserved										OFF		
★ Interface Timing Conversion	50ms LO / 50ms HI								OFF	OFF		
	60ms LO / 300ms HI								ON	OFF		
	30ms LO / 50ms HI								OFF	ON		
	150ms LO / 150ms HI								ON	ON		

★ Manufacture setting

Note : (1) After setting dip switch of the credit pulses,you should reset the bill acceptor again.

(2) Calibration card is needed.

## XBA mini-GNF5(Pulse/MDB/JPSTD/ICT104U/ICT104V)

### Interface Settings: 2(Pulse)

INTERFACE	SW1	SW2	SW3	SW4
★ Credit-Pulse Normal HIGH	ON			
Credit-Pulse Normal LOW	OFF			
★ Pulse Mode		ON		
Other Mode		OFF		
★ 1 pulse / GNF 1000			OFF	OFF
2 pulses /GNF 1000			OFF	ON
5 pulses / GNF 1000			ON	OFF
20 pulses / GNF 1000			ON	ON

★ Manufacture setting

### Interface Settings: 2(Other)

INTERFACE	SW1	SW2	SW3	SW4
★ Reserved	ON			
Reserved	OFF			
Pulse Mode		ON		
Other Mode		OFF		
MDB Mode			OFF	OFF
JPSTD Mode			OFF	ON
ICT104U Mode			ON	OFF
ICT104V Mode			ON	ON

★ Manufacture setting

### Interface Settings: 2(ICT104V)

INTERFACE	SW1	SW2	SW3	SW4
★ Connect with coin changer	ON			
Connect with ICT VCCS Converter board	OFF			
Pulse Mode		ON		
Other Mode		OFF		
MDB Mode			OFF	OFF
JPSTD Mode			OFF	ON
ICT104U Mode			ON	OFF
★ ICT104V Mode			ON	ON

★ Manufacture setting

### Interface Settings: 2(MDB)

FUNCTION	SW1	SW2	SW3	SW4
★ Scaling Factor (SF) = 1 Decimal Point Position (DPP) = 0	ON			
Scaling Factor (SF) = 10 Decimal Point Position (DPP) = 1	OFF			
Pulse Mode		ON		
Other Mode		OFF		
★ MDB Mode			OFF	OFF
JPSTD Mode			OFF	ON
ICT104U Mode			ON	OFF
ICT104V Mode			ON	ON

★ Manufacture setting

### Currency Assign Data

Interface Bill value	ICT104U	ICT104V	JPSTD	Pulse	MDB
BV1	GNF 1000	GNF 1000	GNF 1000	GNF 1000	GNF 1000
BV2	GNF 2000	GNF 2000	GNF 2000	GNF 2000	GNF 2000
BV3	GNF 5000	GNF 5000	GNF 5000	GNF 5000	GNF 5000
BV4	GNF10000	GNF10000	GNF10000	GNF10000	GNF10000
BV5	GNF20000	GNF20000	GNF20000	GNF20000	GNF20000