

BR2300-BRL6

BR2300 DIP SWITCHES SETTING : (MDB/ICT-BC/ccTalk)

Supported bill BRL 2, 5, 10, 20, 50, 100 6bills.

	FUNCTION	SW1	SW2	SW3	SW4	SW5	SW6	SW7	SW8	SW9	SW10
	Reject BRL 2 & 5	ON									
★	Accept BRL 2 & 5	OFF									
	Reject BRL 10 & 20		ON								
★	Accept BRL 10 & 20		OFF								
	Reject BRL 50 & 100			ON							
★	Accept BRL 50 & 100			OFF							
	High Acceptance (Note.3)				ON						
★	High Security				OFF						
★	Scaling Factor (SF) = 100 Decimal Point Position (DPP) = 2 (MDB Only)					ON					
	Scaling Factor (SF) = 1 Decimal Point Position (DPP) = 0					OFF					
★	Normal						OFF	OFF			
	Load Banknote to Recycle						ON	OFF			
	Load Banknote to Stacker						OFF	ON			
	Unload Banknote to Stacker						ON	ON			
★	ccTalk								ON	OFF	
	ccTalk (Note.1)								OFF	ON	
★	MDB Mode								OFF	OFF	
★	ICT-BC Mode								ON	ON	
	ccTalk	MDB Mode			ICT-BC Mode						
★	Encryption MODE	★ Virtual MDB Recycler Function (Note.2)			Connect with MDB Connector						ON
	Decrypt MODE	Standard MDB Recycler Function			★ Connect with RS232 Connector						OFF

★ Manufacture setting

After setting dip switch of the credit pulses, you should reset the bill acceptor again.

Note.1: Turn this dip to with restart the bill acceptor will restore ccTalk address to its default value of 40 and the encryption key to its default value of 123456.

Note.2: Recycled Banknote represents virtual MDB coin type.

Note.3: High acceptance mode will increasing accepting rate, however, it will reduce the security level of Bill Acceptor.

Note.4: Calibration card is needed.

BR2300-BRL6(MDB/ICT-BC/ccTalk)

Currency Assign Data

Interface Bill value	MDB	ICT-BC	ccTalk	Recycler banknote inventory	
BV1	BRL 2	BRL 2	BRL 2	BRL 2	45 pcs
BV2	BRL 5	BRL 5	BRL 5	BRL 5	45 pcs
BV3	BRL 10	BRL 10	BRL 10	BRL 10	45 pcs
BV4	BRL 20	BRL 20	BRL 20	BRL 20	45 pcs
BV5	BRL 50	BRL 50	BRL 50	BRL 50	40 pcs
BV6	BRL 100	BRL 100	BRL 100	BRL 100	40 pcs