

BR2300-HUF6

BR2300 DIP SWITCHES SETTING : (MDB/ICT-BC/ccTalk)

Supported bill HUF 500, 1000, 2000, 5000, 10000, 20000 6bills.

	FUNCTION	SW1	SW2	SW3	SW4	SW5	SW6	SW7	SW8	SW9	SW10
★	Reject HUF 500 & 1000	ON									
★	Accept HUF 500 & 1000	OFF									
★	Reject HUF 2000 & 5000		ON								
★	Accept HUF 2000 & 5000		OFF								
★	Reject HUF 10000 & 20000			ON							
★	Accept HUF 10000 & 20000			OFF							
★	High Acceptance (Note.3)			ON							
★	High Security			OFF							
★	Scaling Factor (SF) = 100 Decimal Point Position (DPP) = 2 (MDB Only)					ON					
★	Scaling Factor (SF) = 1 Decimal Point Position (DPP) = 0					OFF					
★	Normal						OFF	OFF			
	Load Banknote to Recycle						ON	OFF			
	Load Banknote to Stacker						OFF	ON			
	Unload Banknote to Stacker						ON	ON			
★	ccTalk								ON	OFF	
	ccTalk (Note.1)								OFF	ON	
★	MDB Mode								OFF	OFF	
★	ICT-BC Mode								ON	ON	
	ccTalk	MDB Mode			ICT-BC Mode						
★	Encryption MODE	★ Virtual MDB Recycler Function (Note.2)			Connect with MDB Connector						ON
	Decrypt MODE	Standard MDB Recycler Function			★ Connect with RS232 Connector						OFF

★ Manufacture setting

After setting dip switch of the credit pulses, you should reset the bill acceptor again.

Note.1: Turn this dip to with restart the bill acceptor will restore ccTalk address to its default value of 40 and the encryption key to its default value of 123456.

Note.2: Recycled Banknote represents virtual MDB coin type.

Note.3: High acceptance mode will increase accepting rate, however, it will reduce the security level of Bill Acceptor.

Note.4: Calibration card is needed.

BR2300-HUF6(MDB/ICT-BC/ccTalk)

Currency Assign Data

Interface Bill value	ccTalk	ICT-BC	MDB	Recycler banknote inventory	
BV1	HUF 500	HUF 500	HUF 500	HUF 500	40 pcs
BV2	HUF 1000	HUF 1000	HUF 1000	HUF 1000	40 pcs
BV3	HUF 2000	HUF 2000	HUF 2000	HUF 2000	40 pcs
BV4	HUF 5000	HUF 5000	HUF 5000	HUF 5000	40 pcs
BV5	HUF 10000	HUF 10000	HUF 10000	HUF 10000	40 pcs
BV6	HUF 20000	HUF 20000	HUF 20000	HUF 20000	40 pcs