BR2300-SAR4

BR2300 DIP SWITCHES SETTING: (MDB/ICT-BC/ccTalk) Supported bill SAR 1, 5, 10, 50 4bills.

	FUNCTION		SW1	SW2	SW3	SW4	SW5	SW6	SW7	SW8	SW9	SW10
	Reject SAR 1		ON									
*	Accept SAR 1		OFF									
	Reject SAR 5 & 10			ON								
*	Accept SAR 5 & 10			OFF								
	Reject SAR 50				ON							
*	Accept SAR 50				OFF							
	High Acceptance (Note.3)					ON						
*	High Security					OFF						
*	Scaling Factor (SF) = 100 Decimal Point Position (DPP) = 2		(MDB On	ly)			ON					
	Scaling Factor (SF) = Decimal Point Position (DF						OFF					
*	Normal			OFF OFF								
	Load Banknote to Recycle			ON OFF								
	Load Banknote to Stacker			OFF ON								
	Unload Banknote to Stacker							ON	ON			
*	ccTalk									ON	OFF	
	ccTalk								OFF	ON		
*	MDB Mode			OFF OFF								
*	ICT-BC Mode									ON	ON	
	ccTalk		MDE	DB Mode			ICT-BC Mo			de		
*	Encryption MODE	Virtual MDB Recycler Function (Note.2)			ote.2)	Connect with MDB Conne				ector	ON	
	Decrypt MODE	Standard MDB Recycler Fo				on	Connect with RS232 Connector					OFF

★ Manufacture setting

After setting dip switch of the credit pulses, you should reset the bill acceptor again.

Note,1: Turn this dip to with restart the bill acceptor will restore ccTalk address to its default value of 40 and the encryption key to its default value of 123456.

Note.2 Recycked Banknote represents virtual MDB coin type.

Note.3: High acceptance mode will increasing accepting rate, however, it will reduce the security level of Bill Acceptor.

Note.4: Calibration card is needed.

BR2300-SAR4 (MDB/ICT-BC/ccTalk)

Currency Assign Data

Interface ccTalk		ICT-BC	MDB	Recycler banknote inventory			
BV1	SAR 1	SAR 1	SAR 1	SAR 1	45 pcs		
BV2	SAR 5	SAR 5	SAR 5	SAR 5	40 pcs		
BV3	SAR 10	SAR 10	SAR 10	SAR 10	40 pcs		
BV4							
BV5	SAR 50	SAR 50	SAR 50	SAR 50	40 pcs		