BRV-SGD2

BRV Option Switch Settings: 1(ICT-BC/MDB/JPSTD Dummy) Supported bill SGD 2, 5 2bills.

BRV dip-switch settings and functions:

	FUNCTION	SW1	SW2	SW3	SW4	SW5	SW6	SW7	SW8	SW1	SW2	SW3	SW4
	Reject SGD 2	ON											
*	Accept SGD 2	OFF											
	Reject SGD 5		ON										
*	Accept SGD 5		OFF										
	Reserved			ON									
*	Reserved			OFF									
	Reserved				ON								
*	Reserved				OFF								
	Reserved					ON							
*	Reserved					OFF							
*	Normal				OFF	OFF							
	Load Banknote to Recycle	ON OFF											
	Load Banknote to Stacker	OFF ON											
	Unload Banknote to Stacker	ON ON											
	Reserved	ON											
*	Reserved	OFF					OFF						
	MDB Mode	SW1	SW2	SW3	SW4	JPS	TD Du	mmy	Mode				
	Reserved	ON			*		Note Limit			ON	ON	ON	
*	Reserved	OFF				1 Bank Note Limitation Per Transaction 2 Bank Note Limitation Per Transaction			OFF	OFF	OFF		
	Reserved		ON			3 Bank Note Limitation Per Transaction			OFF	ON	OFF		
*	Reserved		OFF			4 Bank Note Limitation Per Transaction		ON	ON	OFF			
	Reserved			ON		5 Bank Note Limitation Per Transaction 6 Bank Note Limitation Per Transaction		OFF	OFF	ON			
*	Reserved			OFF 7 Bank Note Limitation				OFF	ON	ON			
	Virtual MDB Recycler Function (Note.4)				ON No Refund After the Deal		Deal				ON		
*	Standard MDB Recycler Function				OFF	★Re	fund A	fter the	e Deal				OFF

★ Manufacture setting

Note: (1) After setting dip switch of the credit pulses, you should reset the bill acceptor again.
(2) Please reset the bill acceptor after set the dip switch.
(3) Calibration card is needed.

(4) Recycked Banknote represents virtual MDB coin type.

BRV-SGD2(ICT-BC/MDB/JPSTD Dummy)

Interface Settings: 2(ICT-BC)

INTERFACE	SW5	SW6	SW7	SW8	
Reserved	ON				
Reserved	OFF				
Connect with MDB Connector		ON			
Connect with RS232 Connector		OFF			
MDB Mode			OFF	OFF	
JPSTD Dummy Mode			OFF	ON	
Reserved	Reserved		ON	OFF	
ICT-BC Mode			ON	ON	
	Reserved Reserved Connect with MDB Connector Connect with RS232 Connector MDB Mode JPSTD Dummy Mode Reserved	Reserved ON Reserved OFF Connect with MDB Connector Connect with RS232 Connector MDB Mode JPSTD Dummy Mode Reserved	Reserved ON Reserved OFF Connect with MDB Connector ON Connect with RS232 Connector OFF MDB Mode JPSTD Dummy Mode Reserved	Reserved ON OFF Reserved OFF ON Connect with MDB Connector ON Connect with RS232 Connector OFF MDB Mode OFF JPSTD Dummy Mode OFF Reserved ON	

[★] Manufacture setting

Interface Settings: 2(JPSTD Dummy)

	INTERFACE	SW5	SW6	SW7	SW8
	Escrow (JPSTD Dummy Mode)	ON			
*	No Escrow (JPSTD Dummy Mode)	OFF			
	Reserved		ON		
*	Reserved		OFF		
	MDB Mode			OFF	OFF
*	JPSTD Dummy Mode			OFF	ON
	Reserved	erved			OFF
	ICT-BC Mode			ON	ON
	3 0				

★ Manufacture setting

Interface Settings: 2(MDB)

	INTERFACE	SW5	SW6	SW7	SW8
*	Scaling Factor (SF)= 100 Decimal Point Position (DPP)= 2	ON			
	Scaling Factor (SF)= 1 Decimal Point Position (DPP)= 0	OFF			
	Reserved		ON		
*	Reserved		OFF		
* *	MDB Mode			OFF	OFF
	JPSTD Dummy Mode			OFF	ON
	Reserved			ON	OFF
	ICT-BC Mode			ON	ON

[★] Manufacture setting

Currency Assign Data

Interface Bill value	JPSTD Dummy	ICT-BC	MDB	knote inventory	
BV1	SGD 2	SGD 2	SGD 2	SGD 2	35 pcs
BV2	SGD 5	SGD 5	SGD 5	SGD 5	35 pcs