

# L83-CHF4

## L83-P3/P6 DIP SWITCHES SETTING : 1(Pulse/ccTalk/Parellel A5)

Supported bill CHF 10, 20, 50, 100 4bills.

FUNCTION	SW1	SW2	SW3	SW4	SW5	SW6	SW7	SW8	SW9	SW10
★ 1 Pulse / CHF 10	OFF	OFF	OFF							
2 Pulse / CHF 10	OFF	OFF	ON							
3 Pulse / CHF 10	OFF	ON	OFF							
4 Pulse / CHF 10	OFF	ON	ON							
5 Pulse / CHF 10	ON	OFF	OFF							
10 Pulse / CHF 10	ON	OFF	ON							
20 Pulse / CHF 10	ON	ON	OFF							
100 Pulse / CHF 10	ON	ON	ON							
Fast output Pulse Lo= 50ms Hi=100ms				ON						
★ Slow output Pulse Lo= 50ms Hi=300ms				OFF						
Inhibit level Active Low					ON					
★ Inhibit level Active High					OFF					
★ Accept CHF 10						ON				
Reject CHF 10						OFF				
★ Accept CHF 20							ON			
Reject CHF 20							OFF			
★ Accept CHF 50								ON		
Reject CHF 50								OFF		
★ Accept CHF 100									ON	
Reject CHF 100									OFF	
★ Reserve										ON
Reserve										OFF

★ Manufacture setting

Note:(1) Please reset the bill acceptor after set the dip switch.

(2) Dip switches 1 to 5 are only used for pulse protocol.

(3) Turn this dip to with restart the bill acceptor will restore CCTalk address to its default value of 40 and the encryption key to its default value of 123456.

# L83-CHF4(Pulse/ccTalk/Parallel A5)

## DIP SWITCHES SETTING : 2(Pulse)

FUNCTION	SW1	SW2	SW3	SW4
★ Credit-Pulse Normal High	ON			
Credit-Pulse Normal Low	OFF			
★ Pulse Mode		ON	OFF	
ccTalk Interface		OFF	OFF	
Parallel A5 Mode		ON	ON	
ccTalk Parameters Restore Switch (Please see Note.3 for Detail)		OFF	ON	
★ Reserved				ON
				OFF

★ Manufacture setting

## DIP SWITCHES SETTING : 2(ccTalk)

FUNCTION	SW1	SW2	SW3	SW4
★ CRC 16-bit checksum	ON			
8-bit checksum	OFF			
Pulse Mode		ON	OFF	
★ cctalk Interface		OFF	OFF	
Parallel A5 Mode		ON	ON	
ccTalk Parameters Restore Switch (Please see Note.3 for Detail)		OFF	ON	
★ Encryption Mode				ON
Decrypt Mode				OFF

★ Manufacture setting

Note: Put this switch to on and reset power will restore the ccTalk address to its default value of 40 and the encryption key to its default value of 123456.

## DIP SWITCHES SETTING : 2(Parallel A5)

FUNCTION	SW1	SW2	SW3	SW4
★ Reserved	ON			
	OFF			
Pulse Mode		ON	OFF	
cctalk Interface		OFF	OFF	
★ Parallel A5 Mode		ON	ON	
ccTalk Parameters Restore Switch (Please see Note.3 for Detail)		OFF	ON	
★ Reserved				ON
				OFF

★ Manufacture setting

## Currency Assign Data

Interface Bill value	Pulse	ccTalk	Parallel A5
BV1	CHF 10	CHF 10	CHF 10
BV2	CHF 20	CHF 20	CHF 20
BV3	CHF 50	CHF 50	CHF 50
BV4	CHF 100	CHF 100	CHF 100