

## L83+GSP4(GBP4+SCO3)

### L83+P3/P6 DIP SWITCHES SETTING : 1(Pulse/ccTalk/Smiley Parallel)

**Supported bill GBP 5, 10, 20, 50 4bills.**  
**SCO 5, 10, 20 3bills.**

FUNCTION	SW1	SW2	SW3	SW4	SW5	SW6	SW7	SW8	SW9	SW10
★ 1 Pulse / £ 5	OFF	OFF	OFF							
2 Pulse / £ 5	OFF	OFF	ON							
3 Pulse / £ 5	OFF	ON	OFF							
4 Pulse / £ 5	OFF	ON	ON							
5 Pulse / £ 5	ON	OFF	OFF							
10 Pulse / £ 5	ON	OFF	ON							
20 Pulse / £ 5	ON	ON	OFF							
100 Pulse / £ 5	ON	ON	ON							
Fast output Pulse Lo= 50ms Hi=100ms				ON						
★ Slow output Pulse Lo= 50ms Hi=300ms				OFF						
Inhibit level Active Low				ON						
★ Inhibit level Active High				OFF						
★ Accept £ 5				ON						
Reject £ 5				OFF						
★ Accept £ 10				ON						
Reject £ 10				OFF						
★ Accept £ 20				ON						
Reject £ 20				OFF						
★ Accept £ 50				ON						
Reject £ 50				OFF						
★ Reserved				ON						
Reserved				OFF						

★ Manufacture setting

Note.1 Please reset the bill acceptor after any changes on Dip switch.

Note.2 Dip Switch 1 to 5 are only for Pulse mode.

Note.3 Turn this dip to with restart the bill acceptor will restore ccTalk address to its default value of 40 and the encryption key to its default value of 123456.

## L83+GSP4(GBP4+SCO3)/(Pulse/ccTalk/Smiley Parallel)

### DIP SWITCHES SETTING : 2(Pulse)

FUNCTION	SW1	SW2	SW3	SW4
★ Pulse Normal High	ON			
Pulse Normal Low	OFF			
★ Pulse Mode		ON	OFF	
ccTalk Interface		OFF	OFF	
Smiley Parallel Mode		ON	ON	
ccTalk Parameters Restore Switch (Please see Note.3 for Detail)		OFF	ON	
★ Reserved				ON
				OFF

★ Manufacture setting

### DIP SWITCHES SETTING : 2(ccTalk)

FUNCTION	SW1	SW2	SW3	SW4
★ CRC 16-bit checksum	ON			
8-bit checksum	OFF			
Pulse Mode		ON	OFF	
★ cctalk Interface		OFF	OFF	
Smiley Parallel Mode		ON	ON	
ccTalk Parameters Restore Switch (Please see Note.3 for Detail)		OFF	ON	
★ Encryption Mode				ON
Decrypt Mode				OFF

★ Manufacture setting

Note.3 Turn this dip to with restart the bill acceptor will restore ccTalk address to its default value of 40 and the encryption key to its default value of 123456.

### DIP SWITCHES SETTING : 2(Smiley Parallel)

FUNCTION	SW1	SW2	SW3	SW4
★ Reserved	ON			
	OFF			
Pulse Mode		ON	OFF	
cctalk Interface		OFF	OFF	
★ Smiley Parallel Mode		ON	ON	
ccTalk Parameters Restore Switch (Please see Note.3 for Detail)		OFF	ON	
★ Reserved				ON
				OFF

★ Manufacture setting

### Currency Assign Data

Interface Bill value	Pulse	Smiley Parallel	ccTalk
BV1	£ 5	£ 5	£ 5
BV2	£ 10	£ 10	£ 5
BV3	£ 20	£ 20	£ 5
BV4	£ 50	£ 50	£ 5
BV5			£ 10
BV6			£ 10
BV7			£ 10
BV8			£ 10
BV9			£ 20
BV10			£ 20
BV11			£ 50