

L83-RSD8

L83-P3/P6 DIP SWITCHES SETTING : 1(Pulse/smiley Parallel/ccTalk)

Supported bill RSD 10, 20, 50, 100, 200, 500, 1000, 2000
8bills.

	FUNCTION	SW1	SW2	SW3	SW4	SW5	SW6	SW7	SW8	SW9	SW10
★	1 Pulse / RSD 10	OFF	OFF	OFF							
	2 Pulse / RSD 10	OFF	OFF	ON							
	3 Pulse / RSD 10	OFF	ON	OFF							
	4 Pulse / RSD 10	OFF	ON	ON							
	5 Pulse / RSD 10	ON	OFF	OFF							
	10 Pulse / RSD 10	ON	OFF	ON							
	20 Pulse / RSD 10	ON	ON	OFF							
	100 Pulse / RSD 10	ON	ON	ON							
	Fast output Pulse Lo= 50ms Hi=100ms				ON						
★	Slow output Pulse Lo= 50ms Hi=300ms				OFF						
	Inhibit level Active Low					ON					
★	Inhibit level Active High					OFF					
★	Accept RSD 10 & 20						ON				
	Reject RSD 10 & 20						OFF				
★	Accept RSD 50 & 100							ON			
	Reject RSD 50 & 100							OFF			
★	Accept RSD 200 & 500								ON		
	Reject RSD 200 & 500								OFF		
★	Accept RSD 1000									ON	
	Reject RSD 1000									OFF	
★	Accept RSD 2000										ON
	Reject RSD 2000										OFF

★ Manufacture setting

Note:(1) Please reset the bill acceptor after any changes on Dip switch.

(2) Dip Switch 1 to 5 are only for Pulse mode.

(3) Turn this dip to with restart the bill acceptor will restore ccTalk address to its default value of 40 and the encryption key to its default value of 123456.

L83-RSD8(Pulse/smiley Parallel/ccTalk)

DIP SWITCHES SETTING : 2(Pulse)

	FUNCTION	SW1	SW2	SW3	SW4
★	Pulse Normal High	ON			
	Pulse Normal Low	OFF			
★	Pulse Mode		ON	OFF	
	ccTalk Interface		OFF	OFF	
	Smiley Parallel Mode		ON	ON	
	ccTalk Parameters Restore Switch (Please see Note.3 for Detail)		OFF	ON	
	Encryption Mode				ON
★	Decrypt Mode				OFF

★ Manufacture setting

DIP SWITCHES SETTING : 2(ccTalk)

	FUNCTION	SW1	SW2	SW3	SW4
★	CRC 16-bit checksum	ON			
	8-bit checksum	OFF			
	Pulse Mode		ON	OFF	
★	ccTalk Interface		OFF	OFF	
	Smiley Parallel Mode		ON	ON	
	ccTalk Parameters Restore Switch (Please see Note.3 for Detail)		OFF	ON	
★	Encryption Mode				ON
	Decrypt Mode				OFF

★ Manufacture setting

Note: Put this switch to on and reset power will restore the ccTalk address to its default value of 40 and the encryption key to its default value of 123456.

DIP SWITCHES SETTING : 2(Smiley Parallel)

	FUNCTION	SW1	SW2	SW3	SW4
★	Reserved	ON			
		OFF			
	Pulse Mode		ON	OFF	
	ccTalk Interface		OFF	OFF	
★	Smiley Parallel Mode		ON	ON	
	ccTalk Parameters Restore Switch (Please see Note.3 for Detail)		OFF	ON	
	Encryption Mode				ON
★	Decrypt Mode				OFF

★ Manufacture setting

Currency Assign Data

Interface Bill value	Pulse	ccTalk	Smiley Parallel
BV1	RSD 10	RSD 10	RSD 10
BV2	RSD 20	RSD 20	RSD 20
BV3	RSD 50	RSD 50	RSD 50
BV4	RSD 100	RSD 100	RSD 100
BV5	RSD 200	RSD 200	RSD 200
BV6	RSD 500	RSD 500	RSD 500
BV7	RSD 1000	RSD 1000	RSD 1000
BV8	RSD 2000	RSD 2000	RSD 2000