



UAH7

L83 DIP SWITCHES SETTING : 1(Pulse/ccTalk/Smiley)

Supported bill H 5, 10, 20, 50, 100, 200, 500 7bills.

FUNCTION	SW1	SW2	SW3	SW4	SW5	SW6	SW7	SW8	SW9	SW10
★ 1 Pulse / H 5	OFF	OFF	OFF							
2 Pulse / H 5	OFF	OFF	ON							
3 Pulse / H 5	OFF	ON	OFF							
4 Pulse / H 5	OFF	ON	ON							
5 Pulse / H 5	ON	OFF	OFF							
10 Pulse / H 5	ON	OFF	ON							
20 Pulse / H 5	ON	ON	OFF							
100 Pulse / H 5	ON	ON	ON							
★ Fast output Pulse <small>Lo= 50ms Hi=100ms</small>				ON						
★ Slow output Pulse <small>Lo= 50ms Hi=300ms</small>				OFF						
Inhibit level Active Low					ON					
★ Inhibit level Active High					OFF					
★ Accept H 5 & 10						ON				
Reject H 5 & 10						OFF				
★ Accept H 20 & 50							ON			
Reject H 20 & 50							OFF			
★ Accept H 100								ON		
Reject H 100								OFF		
★ Accept H 200									ON	
Reject H 200									OFF	
★ Accept H 500										ON
Reject H 500										OFF

★ Manufacture setting

Note:(1)Please reset the bill acceptor after set the dip switch.

(2)Dip switches 1 to 5 are only used for pulse protocol.

L83-UAH7(Pulse/ccTalk/Smiley)

DIP SWITCHES SETTING : 2(Pulse)

FUNCTION	SW1	SW2	SW3	SW4
★ Pulse Normal High	ON			
Pulse Normal Low	OFF			
★ Pulse Mode		ON	OFF	
★ Reserved				ON
				OFF

★ Manufacture setting

DIP SWITCHES SETTING : 2(ccTalk)

FUNCTION	SW1	SW2	SW3	SW4
★ Reserved	ON			
	OFF			
★ ccTalk Interface		OFF	OFF	
★ ccTalk Parameters Restore Switch Please see "Note" for detail		OFF	ON	
★ Reserved				ON
				OFF

★ Manufacture setting

Note: Put this switch to on and reset power will restore the CCTalk address to its default value of 40 and the encryption key to its default value of 123456.

DIP SWITCHES SETTING : 2(Smiley)

FUNCTION	SW1	SW2	SW3	SW4
★ Reserved	ON			
	OFF			
★ Smiley Mode		ON	ON	
★ Reserved				ON
				OFF

★ Manufacture setting