

XBA mini-CAD5

XBA mini Option Switch Settings: 1(Pulse/MDB/JPSTD/ICT104V/ICT104U)

Supported bill CAD 5, 10, 20, 50, 100 5bills.

XBA mini dip-switch settings and functions:

FUNCTION	SW1	SW2	SW3	SW4	SW5	SW6	SW7	SW8	SW1	SW2	SW3	SW4
★ Reject CAD 5	ON											
★ Accept CAD 5	OFF											
★ Reject CAD 10		ON										
★ Accept CAD 10		OFF										
★ Reject CAD 20			ON									
★ Accept CAD 20			OFF									
★ Reject CAD 50				ON								
★ Accept CAD 50				OFF								
★ Reject CAD 100					ON							
★ Accept CAD 100					OFF							
★ Disable Bill Reject 4 Times BA Stop By 30 Sec						ON						
★ Enable Bill Reject 4 Times BA Stop By 30 Sec						OFF						
★ Colorful light							OFF	OFF				
★ The green light flashes							OFF	ON				
★ Reserved							ON	OFF				
★ No light							ON	ON				
★ Inhibit Active High									ON			
★ Inhibit Active Low									OFF			
★ Reserved									ON			
★ Reserved									OFF			
★ Interface Timing Conversion	5ms LO / 5ms HI									OFF	OFF	
	5ms LO / 10ms HI									ON	OFF	
	10ms LO / 10ms HI										OFF	ON
	20ms LO / 20ms HI										ON	ON

★ Manufacture setting

After setting dip switch of the credit pulses, you should reset the bill acceptor again.

Note : (1) Calibration card is needed.

XBA mini-CAD5(Pulse/MDB/JPSTD/ICT104V/ICT104U)

Interface Settings: 2(Pulse)

INTERFACE	SW1	SW2	SW3	SW4
★ Credit-Pulse Normal HIGH	ON			
Credit-Pulse Normal LOW	OFF			
★ Pulse Mode		ON		
Other Mode		OFF		
★ 1 pulse / CAD 5			OFF	OFF
2 pulses / CAD 5			OFF	ON
4 pulses / CAD 5			ON	OFF
20 pulses / CAD 5			ON	ON

★ Manufacture setting

Interface Settings: 2(ICT104U)

INTERFACE	SW1	SW2	SW3	SW4
★ Reserved	ON			
Reserved	OFF			
Pulse Mode		ON		
Other Mode		OFF		
MDB Mode			OFF	OFF
JPSTD Mode			OFF	ON
★ ICT104U Mode			ON	OFF
ICT104V Mode			ON	ON

★ Manufacture setting

Interface Settings: 2(ICT104V)

INTERFACE	SW1	SW2	SW3	SW4
★ Connect with coin changer	ON			
Connect with ICT VCCS converter board	OFF			
Pulse Mode		ON		
Other Mode		OFF		
MDB Mode			OFF	OFF
JPSTD Mode			OFF	ON
★ ICT104U Mode			ON	OFF
ICT104V Mode			ON	ON

★ Manufacture setting

Interface Settings: 2(MDB)

FUNCTION	SW1	SW2	SW3	SW4
★ Scaling Factor (SF) = 100 Decimal Point Position (DPP) = 2	ON			
Scaling Factor (SF) = 1 Decimal Point Position (DPP) = 0	OFF			
Pulse Mode		ON		
Other Mode		OFF		
★ MDB Mode			OFF	OFF
JPSTD Mode			OFF	ON
ICT104U Mode			ON	OFF
ICT104V Mode			ON	ON

★ Manufacture setting

Currency Assign Data

Interface Bill value	JPSTD	ICT104U	ICT104V	Pulse	MDB
	BV1	CAD 5	CAD 5	CAD 5	CAD 5
BV2		CAD 10	CAD 10	CAD 10	CAD 10
BV3		CAD 20	CAD 20	CAD 20	CAD 20
BV4		CAD 50	CAD 50	CAD 50	CAD 50
BV5		CAD 100	CAD 100	CAD 100	CAD 100