

XBA mini-MXN8

XBA mini Option Switch Settings: 1(Pulse/MDB/JPSTD/ICT104V/ICT104U)

Supported bill MXN 20, 50, 100, 200 4bills.
USD 1, 5, 10, 20 4bills.

XBA mini dip-switch settings and functions:

	FUNCTION	SW1	SW2	SW3	SW4	SW5	SW6	SW7	SW8	SW1	SW2	SW3	SW4
★	Reject MXN 20 & USD 1	ON											
★	Accept MXN 20 & USD 1	OFF											
★	Reject MXN 50 & USD 5		ON										
★	Accept MXN 50 & USD 5		OFF										
★	Reject MXN 100 & USD 10			ON									
★	Accept MXN 100 & USD 10			OFF									
★	Reject MXN 200 & USD 20				ON								
★	Accept MXN 200 & USD 20				OFF								
★	Reserved				ON								
★	Reserved				OFF								
★	Disable Bill Reject 4 Times BA Stop By 30 Sec					ON							
★	Enable Bill Reject 4 Times BA Stop By 30 Sec					OFF							
★	Stack Banknote when Power-up							ON					
★	Reject Banknote when Power-up							OFF					
★	Reserved								ON				
★	Reserved								OFF				
★	Inhibit Active High									ON			
★	Inhibit Active Low									OFF			
★	Reserved										ON		
★	Reserved										OFF		
★	Interface Timing Conversion	50ms LO / 50ms HI									OFF	OFF	
		60ms LO / 300ms HI									ON	OFF	
		30ms LO / 50ms HI									OFF	ON	
		150ms LO / 150ms HI									ON	ON	

★ Manufacture setting

After setting dip switch of the credit pulses, you should reset the bill acceptor again.

Note : (1) Calibration card is needed.

(2) Exchange Rate on USD to MXN is 1:10

XBA mini-MXN8(Pulse/MDB/JPSTD/ICT104V/ICT104U)

Interface Settings: 2(Pulse)

	INTERFACE	SW1	SW2	SW3	SW4
★	Credit-Pulse Normal HIGH	ON			
	Credit-Pulse Normal LOW	OFF			
★	Pulse Mode		ON		
	Other Mode		OFF		
★	1 pulse / MXN 10			OFF	OFF
	2 pulses / MXN 10			OFF	ON
	5 pulses / MXN 10			ON	OFF
	10 pulses / MXN 10			ON	ON

★ Manufacture setting

Interface Settings: 2(ICT104V)

	INTERFACE	SW1	SW2	SW3	SW4
★	Connect with coin changer	ON			
	Connect with ICT JPSTD converter board	OFF			
★	Pulse Mode		ON		
	Other Mode		OFF		
★	MDB Mode			OFF	OFF
	JPSTD Mode			OFF	ON
	ICT104U Mode			ON	OFF
★	ICT104V Mode			ON	ON

★ Manufacture setting

Interface Settings: 2(MDB)

	FUNCTION	SW1	SW2	SW3	SW4
★	Scaling Factor (SF) = 100 Decimal Point Position (DPP) = 2	ON			
	Scaling Factor (SF) = 1 Decimal Point Position (DPP) = 0	OFF			
★	Pulse Mode		ON		
	Other Mode		OFF		
★	MDB Mode			OFF	OFF
	JPSTD Mode			OFF	ON
	ICT104U Mode			ON	OFF
	ICT104V Mode			ON	ON

★ Manufacture setting

Currency Assign Data

Interface Bill value	JPSTD	ICT104U	ICT104V	Pulse	MDB
BV1	USD 1				
BV2	MXN 20				
BV3	MXN 50 & USD 5				
BV4	MXN 100 & USD 10				
BV5	MXN 200 & USD 20				

Interface Settings: 2(Other)

	INTERFACE	SW1	SW2	SW3	SW4
★	Reserved	ON			
		OFF			
★	Pulse Mode		ON		
	Other Mode		OFF		
★	MDB Mode			OFF	OFF
	JPSTD Mode			OFF	ON
	ICT104U Mode			ON	OFF
	ICT104V Mode			ON	ON

★ Manufacture setting