

XBA-CHF10(CHF4+EUR6) Option Switch Settings

Supported bill Fr 10, 20, 50, 100
 € 5, 10, 20, 50, 100, 200 10bills.


FUNCTION	SW1	SW2	SW3	SW4	SW5	SW6	SW7	SW8
★ Reject Fr 10 & 20 & 50	ON							
★ Accept Fr 10 & 20 & 50	OFF							
★ Reject Fr 100		ON						
★ Accept Fr 100		OFF						
★ Reject € 5 & 10			ON					
★ Accept € 5 & 10			OFF					
★ Reject € 20 & 50				ON				
★ Accept € 20 & 50				OFF				
★ Reject € 100(2019) & 200(2019)					ON			
★ Accept € 100(2019) & 200(2019)					OFF			
★ Disable Bill Reject 4 Times BA Stop By 30 Sec						ON		
★ Enable Bill Reject 4 Times BA Stop By 30 Sec						OFF		
★ Stack Banknote when Power-up							ON	
★ Reject Banknote when Power-up							OFF	
★ Reserved								ON
★ Reserved								OFF

★ Manufacture setting

Currency Assign Data

Interface Bill value	ICT104U	JPSTD	ccTalk	Pulse	RS232 A0
BV1	Fr 10	Fr 10	Fr 10	Fr 10	Fr 10
BV2	Fr 20		Fr 20	Fr 20	Fr 20
BV3	Fr 50		Fr 50	Fr 50	Fr 50
BV4	Fr 100		Fr 100	Fr 100	Fr 100
BV5	€ 5		€ 5	€ 5	€ 5
BV6	€ 10		€ 10	€ 10	€ 10
BV7	€ 20		€ 20	€ 20	€ 20
BV8	€ 50		€ 50	€ 50	€ 50
BV9	€ 100		€ 100	€ 100	€ 100
BV10	€ 200		€ 200	€ 200	€ 200

This dip switch is located at the side of XBA.



ESCROW DATA	
Code	Denomination
66h	Fr 50
67h	Fr 100
72h	€ 5
73h	€ 10
74h	€ 20
75h	€ 50
76h	€ 100
77h	€ 200

CURRENCY ASSIGN DATA			
Code	Country	Denomination	EXP
66h	16h	05h	01h
67h	16h	0Ah	01h
72h	E0h	05h	00h
73h	E0h	0Ah	00h
74h	E0h	14h	00h
75h	E0h	32h	00h
76h	E0h	0Ah	01h
77h	E0h	14h	01h

ESCROW DATA		CURRENCY ASSIGN DATA			
Code	Denomination	Code	Country	Denomination	EXP
64h	Fr 10	64h	16h	01h	01h
65h	Fr 20	65h	16h	02h	01h

Appendix

XBA-CHF10(Pulse/JPSTD/ccTalk/ICT104U/RS232 A0)

FUNCTION		SW1	SW2	SW3	SW4	SW5	SW6	SW7	SW8
Pulse Mode	Other Mode								
Inhibit Active HIGH	Table.1	ON							
Inhibit Active LOW	Table.1	OFF							
Reserved	Reserved		ON						
Reserved	Reserved		OFF						
50ms LO/ 50ms HI	Reserved			OFF	OFF				
50ms LO/ 100ms HI	Reserved			OFF	ON				
65ms LO/ 75ms HI	Reserved			ON	OFF				
100ms LO/ 150ms HI	Reserved			ON	ON				
Credit-Pulse Normal HIGH	Table.1					ON			
Credit-Pulse Normal LOW	Table.1					OFF			
Pulse Mode	Pulse Mode						ON		
Other Mode	Other Mode						OFF		
1 pulse / € 5	ccTalk Mode							OFF	OFF
5 pulses / € 5	RS232 A0 Mode							OFF	ON
10 pulses / € 5	ICT104U Mode							ON	OFF
25 pulses / € 5	JPSTD Mode							ON	ON

★ Manufacture setting

- Note :**
1. After setting dip switch of the credit pulses, you should reset the bill acceptor again.
 2. ccTalk address to its default value of 40 and the encryption key to its default value of 123456.
 3. Calibration card is needed.

Table 1

	SW1	SW5
8-Bit Checksum	OFF	OFF
Restore mode(Note.2)	OFF	ON
CRC 16-Bit Decrypt Checksum	ON	OFF
CRC 16-Bit Encryption Checksum	ON	ON

This dip switch is located on the CPU board, remove the CPU board cover first.

