
## **XBA-MYR6 Option Switch Settings**

Supported bill M\$ 1, 5, 10, 20, 50, 100 6bills.

	FUNCTION	SW1	SW2	SW3	SW4	SW5	SW6	SW7	SW8
	Reject M\$ 1	ON							
*	Accept M\$ 1	OFF							
	Reject M\$ 5		ON						
*	Accept M\$ 5		OFF						
	Reject M\$ 10			ON					
*	Accept M\$ 10			OFF					
	Reject M\$ 20				ON				
*	Accept M\$ 20				OFF				
	Reject M\$ 50 & 100					ON			
*	Accept M\$ 50 & 100					OFF			
	Disable Bill Reject 4 Times BA Stop By 30 Sec						ON		
*	Enable Bill Reject 4 Times BA Stop By 30 Sec	OFF							
	Stack Banknote when Power-up							ON	
*	Reject Banknote when Power-up	OFF							
	ENABLE IrDA Download								ON
$\star$	Reserved						OFF		

## This dip switch is located at the side of XBA.



## **Currency Assign Data**

_											
	Interface Bill value	ICT002U		ICT104U		ICT104V		Pulse		MDB	
I	BV1	M\$	1	М\$	1	M\$	1	М\$	1	M\$	1
ſ	BV2										
I	BV3	M\$	5	M\$	5	M\$	5	M\$	5	M\$	5
Γ	BV4	M\$	10	M\$	10	M\$	10	M\$	10	M\$	10
	BV5	M\$	50	M\$	50	M\$	50	M\$	50	M\$	50
ſ	BV6	M\$	100	M\$	100	M\$	100	M\$	100	M\$	100
	BV7	М\$	20	M\$	20	M\$	20	M\$	20	M\$	20

## XBA-MYR6 (Pulse/MDB/ICT002U/ICT104U/ICT104V)


		ī						1		
	FUNCTION	SW1	SW2	SW3	SW4	SW5		SW6	SW7	SW8
	Inhibit Active HIGH	ON								
*	Inhibit Active LOW	OFF								
	Reserved		ON							
*	Reserved		OFF							
	Reserved			ON						
*	Reserved			OFF						
	Reserved				ON					
*	Reserved				OFF		_			
	Pulse Mode	MDB Mode				ICT104V Mode				
*	Credit-Pulse Normal HIGH	Scaling Factor (SF) = 100 Decimal Point Position (DPP) = 2 Scaling Factor (SF) = 1 Decimal Point Position (DPP) = 0				Connect with coin changer	ON			
	Credit-Pulse Normal LOW					Connect with ICT VCCS converter board	OFF			
*	Pulse Mode							ON		
	Other Mode							OFF		
	Pulse Mode	Other Mode								
*	1 pulse / M\$ 1	MDB Mode							OFF	OFF
	5 pulses / M\$ 1	ICT002U Mode							OFF	ON
	10 pulses / M\$ 1	ICT104U Mode							ON	OFF
	25 pulses / M\$ 1	ı	CT10	4V Mc	de				ON	ON

★ Manufacture setting

**Note:** 1. After setting dip switch of the credit pulses, you should reset the bill acceptor again.

2. Calibrate card.

This dip switch is located on the CPU board, remove the CPU board cover first.



© 2013 International Currency Technologies Corporation Vol. 6.0 Part Number : SWT8MY660-R